



# Operation and Installation manual

SOLIVIA 15 EU G4 TL and  
SOLIVIA 20 EU G4 TL

EU





This manual is subject to change.  
Please check our website at [www.solar-inverter.com](http://www.solar-inverter.com)  
for the most up-to-date manual version.

© Copyright – Delta Energy Systems (Germany) GmbH - All rights reserved.

This manual accompanies our equipment for use by the end users.

The technical instructions and illustrations contained in this manual are to be treated as confidential and no part may be reproduced without the prior written permission of Delta Energy Systems Service engineers and end users may not divulge the information contained herein or use this manual for purposes other than those strictly connected with correct use of the equipment.

All information and specifications are subject to change without notice.

---

# Table of Contents

<b>1. General Information.</b>	<b>10</b>
1.1 About this Manual	10
1.2 Safety Symbols & Instruction	10
1.3 Validity	10
1.4 Product Description	10
1.5 Application & Usage	11
1.6 Grid Interface.	11
1.7 Additional Information	11
1.8 Monitoring	12
<b>2. Preparing for Installation</b>	<b>13</b>
2.1 Instruction before Installing	13
2.2 Checking the Package	13
2.3 Unpacking	14
2.4 Identify the Inverter.	15
<b>3. Product Overview</b>	<b>16</b>
3.1 Dimension	16
3.2 Function Introduction.	17
3.2.1 LCD Display and Buttons	19
3.2.2 Inverter Input/Output Interface	19
3.2.3 Air outlet	20
<b>4. Installation.</b>	<b>22</b>
4.1 Installing Location	22
4.2 Mounting	23
4.3 Ambient temperature.	26
<b>5. Wiring the Inverter</b>	<b>28</b>
5.1 Preparation before Wiring	28
5.2 AC Grid Connection: 3 Phase + N + PE	30
5.2.1 AC bayonet connector	31
5.3 DC Connection (from PV array)	35
5.4 Efficiency.	37
5.5 Communication Module Connections	38
5.5.1 RS485 Connection	40
5.5.2 EPO (Emergency Power Off) Connections	41



---

5.5.3	Dry Contact Connection . . . . .	42
<b>6.</b>	<b>Operating the PV inverter . . . . .</b>	<b>43</b>
6.1	Disconnection Parameter Settings . . . . .	45
6.1.1	Power Disconnection Device (PDD) Settings . . . . .	45
6.1.2	SPI device . . . . .	46
6.2	Home Page . . . . .	47
6.3	LCD Flow Chart . . . . .	47
6.3.1	Power Meter . . . . .	48
6.3.2	Statistics . . . . .	48
6.3.3	Logs . . . . .	49
6.3.3.1	Internal Data . . . . .	49
6.3.3.2	Events Journal . . . . .	49
6.3.4	Actual data . . . . .	50
6.3.5	Inverter Information . . . . .	51
6.3.6	Settings . . . . .	51
6.3.6.1	General Settings . . . . .	52
6.3.6.2	Install Settings . . . . .	52
6.3.6.3	Active/Reactive Power control for DE LVD and DE MVD . . . . .	53
6.3.6.3.1	Power Limit . . . . .	55
6.3.6.3.2	Power vs. Frequency . . . . .	56
6.3.6.3.3	Constant $\cos \varphi$ . . . . .	58
6.3.6.3.4	$\cos \varphi(P)$ . . . . .	58
6.3.6.3.5	Constant Reactive Power . . . . .	59
6.3.6.3.6	$Q(V)$ . . . . .	60
6.3.6.3.7	Fault Ride Through (FRT) . . . . .	61
6.3.6.4	Active/Reactive Power control for Italy CEI 0-21 and Italy A70 . . . . .	63
6.3.6.4.1	Power Limit . . . . .	64
6.3.6.4.2	Power vs. Frequency . . . . .	65
6.3.6.4.3	Constant $\cos \varphi$ . . . . .	67
6.3.6.4.4	$\cos \varphi(P)$ . . . . .	67
6.3.6.4.5	Constant Reactive Power . . . . .	69
6.3.6.4.6	$Q(V)$ . . . . .	69
6.3.6.4.7	LVFRT Low Voltage Fault Ride Through (LVFRT) . . . . .	71
<b>7.</b>	<b>Maintenance . . . . .</b>	<b>73</b>
7.1	Cleaning the Fans . . . . .	73
7.2	Replace a Fan . . . . .	75

---

---

7.3	Cleaning the Air Outlets . . . . .	75
<b>8.</b>	<b>Measurements and Messages . . . . .</b>	<b>77</b>
8.1	Measurements . . . . .	77
8.2	Messages . . . . .	82
<b>9.</b>	<b>Troubleshooting. . . . .</b>	<b>84</b>
<b>10.</b>	<b>Decommissioning. . . . .</b>	<b>88</b>
<b>11.</b>	<b>Technical data. . . . .</b>	<b>89</b>
11.1	Specification . . . . .	89
11.2	Cable Recommendations . . . . .	90
11.3	Earthing Systems . . . . .	91
<b>12.</b>	<b>Certificates . . . . .</b>	<b>92</b>

## Figures

Figure 1.1.:	Solar Inverter System Operation Illustration . . . . .	11
Figure 2.1.:	Unpacking Process . . . . .	14
Figure 2.2.:	The Type Label . . . . .	15
Figure 3.1.:	Dimensions of SOLIVIA 15 TL / 20 TL . . . . .	16
Figure 3.2.:	Inverter Exterior View . . . . .	17
Figure 3.3.:	Grounding Kit . . . . .	18
Figure 3.4.:	LCD Display and Control Panel . . . . .	19
Figure 3.5.:	Input/Output Interface . . . . .	20
Figure 3.6.:	Air Outlet Illustration . . . . .	20
Figure 3.7.:	Fan Control . . . . .	21
Figure 4.1.:	SOLIVIA 15 TL and 20 TL protection classes . . . . .	22
Figure 4.2.:	Attaching the mounting bracket to the wall . . . . .	24
Figure 4.3.:	Correct and Incorrect Installation Illustration . . . . .	25
Figure 4.4.:	Proper Installation Gap . . . . .	26
Figure 4.5.:	Derating curve . . . . .	27
Figure 5.1.:	Connection of system if DC inputs are floating . . . . .	29
Figure 5.2.:	Connection of system with Positive Ground or Negative Ground <sup>^</sup> . . . . .	30
Figure 5.3.:	AC cable stripping requirements . . . . .	31
Figure 5.4.:	AC plug sealing ring. . . . .	32
Figure 5.5.:	AC plug illustration . . . . .	34
Figure 5.6.:	Input/Output Interface . . . . .	35
Figure 5.7.:	DC Wiring Illustration . . . . .	36
Figure 5.8.:	SOLIVIA 15 TL Efficiency Curve . . . . .	37
Figure 5.9.:	SOLIVIA 20 TL Efficiency Curve . . . . .	38
Figure 5.10.:	Communication module removal . . . . .	39
Figure 5.11.:	Multi-inverter Connection Illustration . . . . .	40
Figure 5.12.:	Terminal Resistor Switch for Multi-inverter Connection . . . . .	41
Figure 5.13.:	Dry contact connection . . . . .	42
Figure 6.1.:	Country Settings on initial startup . . . . .	43
Figure 6.2.:	LCD Display and Control Panel . . . . .	44
Figure 6.3.:	Grid Settings for LVD and MVD . . . . .	45
Figure 6.4.:	Home page . . . . .	47
Figure 6.6.:	Power Meter Pages . . . . .	48

---

Figure 6.7.:	Statistics Pages . . . . .	49
Figure 6.8.:	Internal Data Flow Chart . . . . .	49
Figure 6.9.:	Events Journal Flow Chart . . . . .	50
Figure 6.10.:	Actual Data Flow Chart . . . . .	50
Figure 6.11.:	Inverter Information Page . . . . .	51
Figure 6.12.:	Settings Page . . . . .	51
Figure 6.13.:	General Settings Page . . . . .	52
Figure 6.14.:	Install Settings Page - Installer Mode . . . . .	53
Figure 6.15.:	Insulation Settings - Installer Mode . . . . .	53
Figure 6.16.:	Active/Reactive Power settings page . . . . .	54
Figure 6.17.:	Power Limit settings page. . . . .	55
Figure 6.18.:	LVD Curve power vs. frequency . . . . .	55
Figure 6.19.:	MVD Curve power vs. frequency . . . . .	55
Figure 6.20.:	Power vs. Frequency . . . . .	56
Figure 6.21.:	Constant $\cos \phi$ settings page . . . . .	56
Figure 6.22.:	$\cos \phi(P)$ settings page . . . . .	57
Figure 6.23.:	Constant Reactive Power settings page . . . . .	58
Figure 6.24.:	Q(U) settings page . . . . .	59
Figure 6.25.:	Fault Ride Through settings page. . . . .	60
Figure 6.26.:	Italy Selftest Flow Chart. . . . .	62
Figure 7.1.:	Steps of removing the fan bracket from the inverter . . . . .	64
Figure 7.2.:	Removing the fan from the fan bracket . . . . .	65
Figure 7.3.:	Removing the Vent Covers for Cleaning . . . . .	66
Figure 8.1.:	Measurements on the Home Page . . . . .	67
Figure 8.2.:	Measurements on the Power Meter Pages . . . . .	68
Figure 8.3.:	Measurements on the Statistics Pages . . . . .	69
Figure 8.4.:	Measurements on the Actual Data Pages . . . . .	70
Figure 8.5.:	Measurements of Temperature on the Actual Data Pages . . . . .	71
Figure 9.6.:	LED Indicator . . . . .	74
Figure 11.1.:	Earthing Systems . . . . .	82

---

## Tables

Table 2.1.:	Packing List . . . . .	13
Table 5.1.:	Permitted earthing systems . . . . .	31
Table 5.2.:	Definition of RS485 pin . . . . .	40
Table 5.3.:	RS485 Data Format. . . . .	41
Table 5.4.:	EPO pin assignment . . . . .	41
Table 6.1.:	LED indicator . . . . .	45
Table 8.1.:	Home Page Measurements and Description . . . . .	67
Table 8.2.:	Power Meter Pages Measurements and Description . . . . .	68
Table 8.3.:	Statistics Pages Measurements and Description . . . . .	69
Table 8.4.:	Actual Data Pages Measurement and Description . . . . .	71
Table 8.5.:	Temperature Measurement and Description . . . . .	71
Table 9.1.:	Troubleshooting Message/Solution Description. . . . .	77

# 1. General Information

## 1.1 About this Manual

This manual provides the detail information for the specification, installation procedures and all related functional settings of the solar inverter model - SOLIVIA 15EUG4TL / SOLIVIA 20EUG4TL. Installation technicians must be well-trained and qualified for installing solar system and must follow all the safety instruction and installation procedures.

## 1.2 Safety Symbols & Instruction



### **CAUTION!**

Machine and equipment damage may occur if this hazardous situation is not avoided



### **WARNING!**

Death and serious injury may occur if this hazardous situation is not avoided



### **DANGER!**

Death and serious injury will occur if this hazardous situation is not avoided



### **WARNING! BURN HAZARD**

The enclosure temperature may exceed 70° C while inverter is in operation. A dangerous burn hazard is present in this situation. Please do not touch!

## 1.3 Validity

This user manual describes the installation procedures, maintenance, technical data and safety instruction of the following solar inverter models under the DELTA brand.

- **SOLIVIA 15EUG4TL**
- **SOLIVIA 20EUG4TL**

**Valid with software version: Dsp.-version 1.77, Red.-version 1.35, Comm.-version 1.44**

The software version of your inverter is found on the inverter display. Please find more information in section 6.35 "Inverter Information."

## 1.4 Product Description

The SOLIVIA 15 TL and 20 TL are 3 phase grid-tied solar inverters with reactive power control. These devices convert direct current (DC) electricity from photovoltaic power collected from PV arrays into 3 phase alternating current (AC) to feed the excess capacity back to the local mains

electrical grid. Using cutting-edge technology allows a wide voltage input range (200~1000 V) and high performance efficiency based on a user-friendly operation design. In addition, special DSP (Digital Signal Processor) design decreases the circuit complication and electronic components. Please note that this device does not support off-grid function. The following are the key features of SOLIVIA 15 TL and 20 TL 3 phase grid-tied solar inverters.

### Key Features

- Power Rating: 15/20 kVA
- 3-Phase (3-Phase + N + PE), Grid-tie, Transformerless solar inverter
- Maximum efficiency: > 98.0 % (both models)
- Europe efficiency: 97.8 % for 15 TL and 20 TL
- Reactive power capability (Cap 0.80 - Ind 0.80)
- Low input current harmonic distortion (THD < 3%) @ full load
- 2 MPP Trackers
- Record up to 30 event logs.
- 5" LCD display

The SOLIVIA 15 TL and 20 TL inverters comply with the latest country regulations and standards. Please see the 15 TL and 20 TL specification in section 12.1 in the appendix for the complete list of compliance standards.

## 1.5 Application & Usage

The operation of the solar inverter is as shown as the figure 1-1. In order to save energy and electricity, solar inverters convert the DC input power supplied from the PV array into three-phase AC output power to the grid.

## 1.6 Grid Interface

Several different safety systems make up the grid interface:

- VFM (Voltage and Frequency Monitoring)
- RCD (Residual Current Detection)
- DCD (Direct Current Detection)
- Controlling redundant AC relays for each grid phase.

## 1.7 Additional Information

For more detailed information about the SOLIVIA 15 TL and 20 TL or other related product information, please visit the website at <http://www.solar-inverter.com> for more support.




Figure 1.1.: Solar Inverter System Operation Illustration

## 1.8 Monitoring

The SOLIVIA 15 TL and 20 TL include a display for monitoring performance on location. Remote monitoring is also an option. Please contact your Delta supplier for more information on remote monitoring options.



## 2. Preparing for Installation

### 2.1 Instruction before Installing

Due to the variety of user installation environments, reading the manual thoroughly before installation is strongly recommended. All the installation and start-up procedures must be undertaken by a professional and well-trained technician.

### 2.2 Checking the Package

There might be some unpredictable situations during transportation. Please check if there is any damage to the cardboard carton. After opening the package, please check both the outer case and inner part of this inverter as below.

1. Check the right side on the inverter case to ensure the model number and the specification is the same with the model you have purchased.
2. Check if there are any loose components.
3. Check if all the accessories are in the package, the standard accessories are listed in the below table:

Item	Quantity	Description
15 TL or 20 TL Solar Inverter	1	15 kVA or 20 kVA solar inverter
User Manual	1	User installation and operation instructions
AC Plug	1	Connector for AC connection
Mounting Bracket	1	Bracket to install the inverter on the wall

Table 2.1.: Packing List

#### NOTE



When there is outer or inner damage on the inverter or there is any missing or damaged standard accessories, please contact your inverter supplier for support.

### 2.3 Unpacking

1. Open the top of the cardboard box as shown in the figure below.
2. Remove the top packing material after opening the box.
3. Lift the Inverter out of the package and save the packaging in case of return.




Figure 2.1.: Unpacking Process

## 2.4 Identify the Inverter

User can identify the model number by the information on the product label. The model number, specification as well as the series no. is specified on the product label. In regard to the label location, please refer to the below figure.




Figure 2.2.: The Type Label

### 3. Product Overview

#### 3.1 Dimension




Figure 3.1.: Dimensions of SOLIVIA 15 TL / 20 TL

## 3.2 Function Introduction

Inverter exterior objects are shown on the figure 3-2, and the detail description is in the sections from 3.2.1 to 3.2.3




Figure 3.2.: Inverter Exterior View




Figure 3.3.: Grounding Kit

The chassis has a predrilled hole ① to accept a grounding screw as shown. The maximum torque of the M6 grounding screw is 4.4 Nm. There is a 15 mm diameter unpainted surface around the center of the ground screw hole that allows for a solid ground connection when installing the grounding kit.

### 3.2.1 LCD Display and Buttons





Figure 3.4.: LCD Display and Control Panel

### 3.2.2 Inverter Input/Output Interface




## Product Overview

Figure 3.5.: Input/Output Interface

No.	Designation	Description
①	AC connector	400 V <sub>AC</sub>
②	Communication	2 × RS485, 1 × EPO, 2 × Dry contact
③	DC connector	4 Strings
④	Fans	4 Fans

**NOTE**



The fans shown are without the required protective screen for illustrative purposes

### 3.2.3 Air outlet




Figure 3.6.: Air Outlet Illustration

There are 4 fans in the bottom section of the inverter and all fans work synchronously. If any one fan locks up or is defective, it will cause a fan failure and power derating. If you suspect that there is a problem with a fan please call the Delta support hotline.






Figure 3.7.: Fan Control

# 4. Installation

## 4.1 Installing Location

The SOLIVIA 15 TL and 20 TL can be installed indoors and in protected outdoor areas due to its enclosure protection classes IP65 and IP55. See the figure below for further explanation of the protection classes.

### WARNING



**Death and serious injury may occur if the following instructions are not carefully followed**

- ▶ Do not install the unit near/on flammable objects.
- ▶ Do not install the unit at a location that people can gain entry/touch easily.
- ▶ Mount the unit tightly onto a solid/ smooth wall.
- ▶ In order to ensure the safety of installers, there should be at least two people to handle the installation.
- ▶ When moving the SOLIVIA 15 TL and 20 TL, installer should not stand under material handling machines.

### CAUTION



**Machine and equipment damage may occur.**

- ▶ Do not install the unit at a location that has direct exposure to sunlight.




Figure 4.1.: SOLIVIA 15 TL and 20 TL protection classes

**NOTE**

The fans shown are without the required protective screen for illustrative purposes

The upper section of the inverter, shown in the darker tone above, is sealed from the lower section and rated at IP65 enclosure protection. The lower section of the inverter, containing the cooling mechanisms, is rated at IP55 enclosure protection.

## 4.2 Mounting

This unit utilizes a wall mounting system. Please ensure the installation is perpendicular and with the AC plug at the bottom. Do not install the device on a slanted wall. The dimensions of the mounting bracket are shown in the following figures. There are 12 pcs. of M6 screws required for attaching the mounting plate to the wall. Attach the mounting plate securely to the wall, before attaching the inverter on the mounting plate.

**NOTE**

Please ensure you are using the correct fastener for the material you are attaching the inverter mounting plate to.




Figure 4.2.: Attaching the mounting bracket to the wall




Figure 4.3.: Correct and Incorrect Installation Illustration

## CAUTION



### Machine and equipment damage may occur.

- ▶ Please leave an appropriate gap in between when installing single / several DELTA solar inverter systems.
- ▶ Please install solar inverters at eye level to allow easy observation for operation and parameter setting.
- ▶ Please install solar inverter in a clean and open space.
- ▶ The ambient temperature should be between  $-20^{\circ}\text{C}$  -  $+60^{\circ}\text{C}$ .

There should be sufficient space for product operation as shown in the figure 4-4. If necessary, the installer should increase the gap space for optimum product performance.




Figure 4.4.: Proper Installation Gap

### 4.3 Ambient temperature

The solar inverter can be operated in an ambient temperature between  $-20^{\circ}\text{C}$  ...  $+60^{\circ}\text{C}$ . The following diagram illustrates how the power supplied by the solar inverter is reduced automatically in accordance with the ambient temperature.

The device should be installed in a well-ventilated, cool and dry location.




Figure 4.5.: Derating curve

# 5. Wiring the Inverter

## 5.1 Preparation before Wiring

1. To avoid accidents, please confirm that the PV inverter's power of both DC and AC are switched off.
2. Please confirm whether the input/output of PV inverter's wiring are clearly indicated. Make sure that the value, polarity, voltage and phase are correct.
3. The wiring procedure of a PV system is shown in figure 5-1 and 5-2. Wiring details are described in the following paragraphs.
  - When the DC input is floating, an external transformer is not necessary. Please refer to Figure 5-1 for the connection. The inverter can accept DC inputs in parallel (1 MPP tracker) or separate DC input connections (2 MPP Tracker).
  - Operating in parallel DC inputs (1 MPP Tracker)

Inverter MPPT:	Power sharing decided by each input's impedance
Boost MPPT:	>10 kW, inverter will force to balance the DC1 & DC2 power
	<10 kW, inverter will not force to balance the DC1 & DC2 power
  - Operating in separated DC inputs (2 MPP Trackers)

The max. rating is 10.5kW/30A for each input.

## CAUTION



### Machine and equipment damage may occur.

- When the DC input is a positive ground or negative ground, all of the strings must be connected in parallel and then connected to the inverters. In addition, an external isolation transformer must be installed on the AC side, otherwise, damage will result and the inverter will not work properly. Different DC input wiring needs require different insulation detection settings. To learn more about the settings, please refer to [„6.3.6.2 Install Settings“ on page 54.](#)






Figure 5.1.: Connection of system if DC inputs are floating




Figure 5.2.: Connection of system with Positive Ground or Negative Ground

## 5.2 AC Grid Connection: 3 Phase + N + PE



### WARNING



**Death and serious injury may occur**

- Before engaging in the AC wiring, please ensure the AC 3-phase power is switched off.

Please use properly sized wire to connect to the correct poles (According to the table below)

Current Rating	Wire size	Torque
≤ 30 A	6mm <sup>2</sup> / 10 AWG	≥ 0.9 Nm (10 kg)

AC wiring can be separated into 3-phase (L1, L2, L3), N, and PE. The following earthing configurations are allowed. IT is not allowed. Please see the appendix for further explanation of these earthing systems.

TN-S	TN-C	TN-C-S	TT	IT
Yes	Yes	Yes	Yes	No

Table 5.1.: Permitted earthing systems

## NOTE



TT ist not recommended. Have to besure the voltage of N is very close to PE ( $< 20 V_{rms}$ )

In [Figure 5.5](#), the Amphenol C16-3 AC connector shown can be mated with the inverter's AC plug. After disassembly of the connector, please adhere to the correct polarity for proper AC wiring (this product allows either positive or negative phase sequence). That means the sequence of L1-L3 can be adjusted and the N and PE must be connected.

### 5.2.1 AC bayonet connector

The AC bayonet connector is approved for cable sheath diameters between 11 mm and 20 mm. To install an AC cable, first strip the voltage free line and cable ends as shown below and then follow the sequence in [Figure 5.5](#) to assemble the cable and bayonet connector.





Figure 5.3.: AC cable stripping requirements

## NOTE




For lines with a cable sheath diameter from 16 mm to 20 mm, the cable gland must be adapted accordingly. To do this, cut out the inner section of the blue sealing ring.




This is a rear view of the cable gland.  
For a cable sheath diameter between  
16 mm to 20 mm, please remove the  
inner sealing ring.

*Figure 5.4.: AC plug sealing ring*

The female cable connector needs to be wired as shown below.




Rotate the connector housing and cable gland to remove them from the coupling ring.




Slide the connector housing and cable gland onto the cable.


**NOTE:** Rear view of cable connector



To wire the connector refer to placement of L1, L2, L3, N and PE shown to the left. Screw termination is provided to fix the wires to the contacts.



After wiring the mating connector, screw the connector housing (1) to the coupling ring (3). To do this push the coupling ring (3) to the connector housing (1) and tighten 1-2 Nm.



Next tighten the cable gland (2) to the connector housing (1). Tightening torque for cable sheath diameters between 11 and 20 mm: 6 to 8 Nm. Rotate the coupling ring (3) to mate the connector with the inverter's AC plug.

## Wiring the Inverter

---

Figure 5.5.: AC plug illustration

### CAUTION



**Machine and equipment damage may occur.**

- Observe the pin assignment of the AC bayonet connector. An incorrect assignment can result in the unit being destroyed. The [Figure 5.5](#) pin out diagram shows the connections inside the AC connector.

### NOTE



Make sure the line is provided with a strain relief device. When using cables with a diameter of less than 13 mm (**11 mm ... 13 mm** diameter cable require strain relief), the cable must be relieved just behind the connector.

The connection to the Amphenol AC connector for both models can be made with a flexible or rigid cable with a copper conductor that has a cross section greater than 4.0 mm<sup>2</sup> and which has an installation condition that gives a correction factor equal to one. The AC cable should be protected by a minimum type B 40 Amp breaker.

This connector is developed for connection to copper wires (for other applications please contact Amphenol). The cross section of the cable should be calculated by considering the material used, thermal conditions, length of the cable, the type of installation, and AC voltage drop.

Please note the cable length and the cable cross-section, due to the risk of undesirable temperature rise and power losses. In some countries (e.g. France, Germany) system installation requirements have to be followed (UTE 15712-1, VDE 0100 712). This recommendation will define minimum cable sections and protections against overheating due to high currents. Please make sure that you follow specific requirements in your country.

For the security of your installation and for the safety of the user, please install required safety and protection devices that are applicable for your installation environment (example: automatic circuit breaker and/or overcurrent protection equipment).



### WARNING



**Death and serious injury may occur**

In the case of damage or bodily harm resulting from the use of this device in a way contrary to its intended purpose or as a result of unauthorized modifications made to the parameters of the inverter, Delta will not be held liable in these situations..

The solar inverter must be grounded via the AC connector's PE conductor. To do this, connect the PE conductor to the designated terminal.

The AC connector is protected from unintentional disconnection by a clip mechanism which can be released with a screwdriver.

The AC voltage should be as follows:

- L1-N: 230 V<sub>AC</sub>
- L2-N: 230 V<sub>AC</sub>
- L3-N: 230 V<sub>AC</sub>

### 5.3 DC Connection (from PV array)



#### WARNING



#### Death and serious injury may occur

- When doing DC wiring, please ensure the wiring is connected with the correct polarity.
- When doing DC wiring, please confirm that PV array's power switch is off.




Figure 5.6.: Input/Output Interface

No.	Designation	Description
①	AC connector	400 V <sub>AC</sub>
②	Communication	2 × RS485, 1 × EPO, 2 × Dry contact
③	DC connector	4 Strings
④	Fans	4 Fans

NOTE



The fans shown are without the required protective screen for illustrative purposes

CAUTION



**Machine and equipment damage may occur.**

- ▶ The connection number of PV ARRAY, open circuit voltage and power of String\_1 and String\_2 must be coherent.
- ▶ The connection number of PV ARRAY, open circuit voltage and power of String\_3 and String\_4 must be coherent.
- ▶ The maximum power connected to the 15 TL may not exceed 10 kWp per input or 19 kWp in total.
- ▶ The maximum power connected to the 20 TL may not exceed 13 kWp per input or 25 kWp in total.
- ▶ The maximum open circuit voltage of PV Array must not exceed 1000 V.
- ▶ The range of  $V_{mpp}$  of Input DC1 and Input DC2 shall be 350~800  $V_{DC}$ .
- ▶ The device installed between PV array and inverter must meet the rating of voltage  $<1000 V_{DC}$  and  $<$  short current.

Cable size:

Current rating	Wire size
DC 30 A	6 mm <sup>2</sup> / 10 AWG

DC wiring polarity is divided into positive and negative, which is shown in figure 5-6. The connection should be consistent with the indicated polarity marked on the inverter.





Figure 5.7.: DC Wiring Illustration



A kit to meet UTE 15712-1 requirements is provided for the SOLIVIA 15 TL and 20 TL and can be ordered from Delta with the part number in the following table.

	Designation	Part number Delta
	UTE kit Multi-Contact	EOE90000341

### 5.4 5.4 Efficiency

The best efficiency of the solar inverter is obtained at an input voltage of 640 V.




Figure 5.8.: SOLIVIA 15 TL Efficiency Curve




Figure 5.9.: SOLIVIA 20 TL Efficiency Curve

## 5.5 Communication Module Connections

The communication module supports the communication functions with a computer, also provides 1 EPO (Emergency Power Off) and 2 sets of dry contacts. The parts of the communication module are shown in [Figure 5.10](#). The function of each part is detailed in sections [5.5.1](#) ... [5.5.3](#).




Figure 5.10.: Communication module removal

## Wiring the Inverter

To remove the communication module follow these instructions:

1. Unscrew and remove the two Phillips screws highlighted in red in [Figure 5.10](#).
2. Remove the front plate as shown.
3. Carefully pull out the communication module from the inverter. Remove glands and plugs where applicable.

### 5.5.1 RS485 Connection

The pin definition of RS485 is shown in [Table 5.2](#). The wiring of multi-inverter connections is shown in [Figure 5.11](#).

PIN	FUNCTION
4	GND
7	DATA+
8	DATA-

Table 5.2.: Definition of RS485 pin




Figure 5.11.: Multi-inverter Connection Illustration




Figure 5.12.: Terminal Resistor Switch for Multi-inverter Connection

To engage the internal Terminal Resistor, place switch number 2 on the communication module in the on position.

Baud Rate	Programmable, 2400/4800/9600/19200/38400, default = 19200
Data Bit	8
Stop Bit	1
Parity	N/A

Table 5.3.: RS485 Data Format

### 5.5.2 EPO (Emergency Power Off) Connections

The SOLIVIA 15 TL and 20 TL provides emergency power off functions by using an RJ45 connector. When the outer external switch is shorted, the inverter will shut down immediately. Please see [Table 5.4](#) for the pin definition.

PIN	Definition
1	EPO1
2	EPO1
3	N/A
4	EPO2
5	EPO2
6	N/A
7	N/A
8	N/A

Table 5.4.: EPO pin assignment

NOTE



To shutdown the inverter, short pin 1 and 2 or short pin 4 and 5.

5.5.3 Dry Contact Connection

Provides 2 sets of Dry Contact function - NO1 and NO2. Please refer to [Figure 5.11](#) for connection diagram and read below for more details.

NO1: When the inverter is on the grid, the COM and NO1 will be shorted.

NO2: When the fan fails, COM and NO2 will be shorted.




Figure 5.13.: Dry contact connection

## 6. Operating the PV inverter

### WARNING



#### **Burn hazard!**

The enclosure temperature may exceed 70° C while in operation. Injury may occur owing to the hot surface.

► Please do not touch!

After installation, please confirm the AC, DC, and Communication connections are correct. Follow the steps below to startup the inverter:

1. Check the PV array DC voltage:
  - Uncover the PV arrays and expose them to full sunlight.
  - Measure the PV array open circuit DC voltage across the DC positive (+) and negative (-) terminals in the DC distribution box. This voltage must be greater than 250 V<sub>DC</sub> and less than 1000 V<sub>DC</sub>.
2. Check the AC utility voltage:
  - Using an AC voltmeter to measure the AC utility voltage and ensure the voltage is at approximately the nominal value (Nominal = 230 Vac Line-N).
3. Set all necessary settings:
  - Switch on AC breaker to provide power to the inverter (40 seconds)
  - Check the inverter display.
  - Country & Language settings appear on the display at first startup.

### NOTE



**Countries supported:** Belgium, France, Italy, Netherlands, Spain, Greece, Germany, Czech Republic, Slovakia, Portugal, Bulgaria, Romania, United Kingdom, Australia

**Language supported:** English, Italian, French, German, Dutch & Spanish




Figure 6.1.: Country Settings on initial startup

## Operating the PV inverter

- Set all settings for Date, Time, Inverter ID, Insulation, etc.

### NOTE



- ▶ If selecting **Germany or Italy** as the country, it could be necessary to adjust active and reactive power settings (Information for the settings will come from the local grid operator).
- ▶ If needed please call the local support hotline for assistance in setting up Germany MVD/LVD or Italy CEI 0-21/A70 grid settings.

#### 4. Start up the inverter:

- After finishing the basic settings, turn on DC switches (including the DC switch in inverter), inverter will do some self-tests and start a countdown if there is no problem.
- When operating, check all information on the display is correct (ex. Input voltage, current and power; output voltage, current, power and frequency)

When solar irradiation is sufficient, the device will operate automatically, after the self-auto test is completed successfully (about 2 minutes on the first startup of a day). Please refer to [Figure 6.2](#) showing the LCD Display and Control Panel details. The display includes a 5" graphic LCD with 320x240 dots of resolution and a LED indicator showing inverter status. There are green and red colored LED indicator lights to represent various inverter states of operation. Please refer to Table 6-1 for more detail on the LED indicator.




Figure 6.2.: LCD Display and Control Panel



Inverter Status	Green LED	Red LED
Standby or Countdown	FLASHING - on 1 sec. and off 1 sec.	OFF
Power ON	ON	OFF
Error or Fault	OFF	ON
Night time (No DC)	OFF	OFF
Bootloader mode	FLASHING - on 1 sec. and off 1 sec., first the green LED then the red LED in alternating sequence	

Table 6.1.: LED indicator

## 6.1 Disconnection Parameter Settings

### 6.1.1 Power Disconnection Device (PDD) Settings

This applies to LVD and MVD settings when selecting the grid as DE LVD or DE MVD.

#### NOTE



DE LVD refers to Germany Low Voltage Directive and DE MVD refers to Germany Midvoltage Directive.




Figure 6.3.: Grid Settings for LVD and MVD

The grid settings for Germany LVD and MVD can be tuned according to the local utility requirements. The integrated power disconnection device can be set in three modes: 1) set to default values as recommended by LVD/MVD regulations, or 2) adjustments can be done manually within the allowed parameter ranges according to the LVD/MVD regulations depending on the selected mode, or 3) the device can be switched off.

## Operating the PV inverter

At any time, while you are viewing one of the 4 grid setting windows, you are able to switch off the power disconnection device by simultaneously pressing the up and down buttons and holding for more than 5 seconds.

See the tables below for the LVD/MVD allowed parameter ranges according to the regulations:

When the selected grid is LVD, the following adjustable values are allowed:

Parameter	Name in display	Adjustable values
Rise-in-voltage protection U>	Umax	110 ... 115%

As defined in VDE AR N 4105, only the rise-in-voltage protection Umax shall be designed as 10-minute running mean value protection which prevents the upper voltage limit specified in DIN EN 50160 from being exceeded (monitoring over the power).

When the selected grid is MVD, the following adjustable values are allowed:

Parameter	Name in display	Adjustable values	Recommended by MVD
Rise-in-voltage protection U>>	Crit. Umax	1.00 ... 1.30 $U_n$	1.20 $U_{ns}$
Under-voltage protection U<	Umin	0.10 ... 1.00 $U_n$	0.80 $U_{ns}$
Under-voltage protection U<<	Crit. Umin	0.10 ... 1.00 $U_n$	0.45 $U_{ns}$
Rise-in-frequency protection f>	Fmax	50.0 ... 52.0 Hz	51.5 Hz
Under-frequency protection f>	Fmin	47.5 ... 50 Hz	47.5
Delay time for U<	tUmin	1.5 ... 2.4 s	1.5 ... 2.4 s

### 6.1.2 SPI device

The SPI is a system interface protection device for use in Italy. There is no internal SPI required for this inverter but an external SPI device may be requested. Care must be taken so disconnection settings on the inverter are set so they do not interfere with external SPI device disconnection settings. The password "5555" entered in the Install Settings page when Italy is selected as the Country, enables disconnection parameters to be adjusted directly within the grid settings menu.

## 6.2 Home Page

When the inverter is operating normally, the LCD will show the home page as shown in [Figure 6.4](#). On the home page the user can find the output power, inverter status, E-today, date and time.




Figure 6.4.: Home page

## 6.3 LCD Flow Chart

Press any button to enter the menu page, the selections are shown in [Figure 6.5](#). E-today is on the home page; the content of the rest of the pages will be explained in detail from [6.3.1](#) ... [6.3.6](#).

Menu	21. Jun 2011 13:50
E-Today	
Power Meter	
Statistics	
Logs	
Actual Data	
Inverter Information	
Settings	

Figure 6.5.: Main menu page

- „6.3.1 Power Meter“ on page 48
- „6.3.2 Statistics“ on page 48
- „6.3.3 Logs“ on page 49
- „6.3.4 Actual data“ on page 50
- „6.3.5 Inverter Information“ on page 51
- „6.3.6 Settings“ on page 51

6.3.1 Power Meter




Figure 6.6.: Power Meter Pages

6.3.2 Statistics

After pressing **ENT** on this page, the user can view the historical data about power generation on a yearly, monthly and daily basis.




Figure 6.7.: Statistics Pages

### 6.3.3 Logs

After pressing **ENT** on this page, the user can view the internal log and can view the events log.

#### 6.3.3.1 Internal Data

The internal data shows all messages coming from the inverter. These messages indicate the status of internal processes and also changes on the AC and DC terminals, for example: frequency, voltage, etc.




Figure 6.8.: Internal Data Flow Chart

#### 6.3.3.2 Events Journal

The events journal records all events coming through the RS485 link or made on the display at the user level. Only events that could affect global production are shown in this log.




Figure 6.9.: Events Journal Flow Chart

6.3.4 Actual data

Actual data includes 4 pages and records the maximum and/or minimum historical values, including voltage, current, power and temperature.




Figure 6.10.: Actual Data Flow Chart

### 6.3.5 Inverter Information

This page includes the following information: serial number, firmware version, installation date, and inverter ID. To change the inverter ID, please refer to [„6.3.6.2 Install Settings“ on page 52](#).

Inverter Information		21. Jun 2011 13:50
Serial Number	0946000006	
DSP-Version	1.80	
Red.-Version	1.17	
Comm.-Version	1.16	
Installation Date	05.Jan.2009	
Inverter ID	001	
Baudrate	19200	

IT-Grid Version TN      0.10

Figure 6.11.: Inverter Information Page

#### NOTE



The information shown in [Figure 6.11](#) is for illustration purposes and may not match the actual information displayed on your inverter.

The last menu item is the Italian Software Version only applicable for installations in Italy.

### 6.3.6 Settings

Settings includes General Settings, Install Settings, and Active/Reactive Power Control.

Settings		21. Jun 2011 13:50
General Settings		
Install Settings		
Active/Reactive Power Control		
FRT		

Figure 6.12.: Settings Page

### NOTE



FRT is only accessible if you have selected Germany MVD, Italy CEI 021 or Italy A70 as your grid selection.

#### 6.3.6.1 General Settings

Settings in the General Settings include Language, Date, Time, Screen Saver, Brightness, Contrast, Baud Rate, CO2 saved, Earning Value, and Currency.




Figure 6.13.: General Settings Page

User can set the Language, Date, Time, Screen Saver, LCD Brightness, and Contrast appear on the General Settings page 1. Screen Saver can be adjusted from 5 minutes to 60 minutes. When over the setting time limitation, without the pressing of any buttons, the LCD backlight will go off automatically. Brightness and contrast can be adjusted from 1-5 levels (low to high). On General Settings page 2 the Baud Rate, CO2 Saved, Earning Value and Currency are adjustable. Currency is selectable as Australian Dollar (AUD), Euro (EUR) and Great Britain Pound (GBP).

#### 6.3.6.2 Install Settings

Correct passwords are requested when entering Install Settings. Install Settings for user and installation technicians are different. The password can not be revised. After confirmation of the installer password (5555), user can set Inverter ID and Insulation settings. Country is viewable but not adjustable.






Figure 6.14.: Install Settings Page - Installer Mode

- **Inverter ID:** This setting is used to set unique ID's for installations with more than one inverter. In a multi-inverter installation where the inverters will be in a network, each inverter must have a unique ID.
- **Insulation:** ON means enable the measurement of impedance between Array and PE, will not connect to Grid if failure. Depending on DC wiring conditions, user can set 6 kind of insulation detecting method - ON, Positive Ground, Negative Ground, DC1 only, DC2 Only, or Disable. Installer can select different resistance criteria according the actual conditions.
- **Country:** This is the Country selected during startup (nonadjustable).

Insulation		21. Jun 2011 13:50
Mode	[ ON ]	
Resistance	[ 1200 ] kohm	

Figure 6.15.: Insulation Settings - Installer Mode

### 6.3.6.3 Active/Reactive Power control for DE LVD and DE MVD

Below is an overview of the features that are adjustable to control the production of active and reactive power for Germany LVD and MVD

Feature	Available for		Description
	LVD	MVD	
Active power control			

## Operating the PV inverter

Feature	Available for		Description
	LVD	MVD	
Power limit	x	x	To reduce the maximum power production
Power vs. frequency	x	x	To set the power gradient in dependency of the frequency
Reactive power control			
Constant cos $\phi$	x	x	To set a fixed cos $\phi$ (inductive or capacitive)
cos $\phi$ (p)	x	x	To set a cos $\phi$ (inductive or capacitive) in dependency of the active power ratio $P/P_n$
Constant reactive power		x	To set the reactive power ratio $Q/S_n$ . For MVD grids only.
Q (V)		x	To set the reactive power ratio $Q/S_n$ in dependency of the voltage V. For MVD grids only.





Figure 6.16.: Active/Reactive Power settings page



Note: Before adjusting the Active/Reactive Power settings, a Warning window will be displayed, that you should read and make a selection to continue or to quit. Please see caution messages below related to adjusting the settings.

## CAUTION



### Machine and equipment damage may occur.

- ▶ Please only adjust active and reactive power settings if you are a qualified electrical technician with the knowledge to do so
- ▶ Adjustments may affect energy production
- ▶ Some values entered in the Active/Reactive Power settings must come from the local grid operator. Please check with them before making any adjustments

#### 6.3.6.3.1 Power Limit

User can select set percentage of actual or rated power to limit inverter's output power. Inverter will start the action once the user sets the Mode to "ON". This feature is available for LVD and MVD grids.

Active Power Control		21. Jun 2011 13:50
Set Point	[ 60 ]	%
Actual/Rated Power	[ Rated ]	
Mode	[ ON ]	

Figure 6.17.: Power Limit settings page




Figure 6.18.: Actual Power vs Rated Power

Parameter	Adjustable Values	Description
Set point	0 ... 100%	Sets the power reduction to the adjusted value. The value is multiplied with the value of the Locked power limitation.
Actual/Rated	Actual   Rated	Select Actual or Rated Power
Mode	ON   OFF	Switches the feature on and off.

### 6.3.6.3.2 Power vs. Frequency

User can have two modes: LVD and MVD. The figures below explain the different behaviors for these modes. The inverter activates these modes depending on the country that is selected and the requirements for that country.

This feature is available for LVD and MVD grids. This feature allows the user to set a power reduction in a percent of the maximum power.




Figure 6.19.: LVD Curve power vs. frequency




Figure 6.20.: MVD Curve power vs. frequency

Active Power Control		21. Jun 2010 13:50
(a) Actual/Rated Power	[ Actual ]	
(b) Start Frequency	[ 50.20 ] Hz	
(c) Stop Frequency	[ -- ] Hz	
(d) Recovery Frequency	[ 50.05 ] Hz	
(e) Gradient	[ 40 ] %	
Recovery Time	[ -- ] s	
Mode	[ ON ]	

Figure 6.21.: Power vs. Frequency

## NOTE



The Power vs Frequency function is required for LVD and MVD. Please make sure the Mode is ON and do not turn off.

## Adjustable parameters

Parameter	Adjustable Values	Description
Actual / Rated Power		Actual or Rated can be selected
Start frequency	50.00 ... 55.00	The frequency when the power reduction starts
Stop frequency		Stop frequency means the frequency when power = 0. This value is calculated by the gradient and the start frequency.
Recovery frequency	50.00 ... 55.00	This feature is only for MVD. This value is equal to the frequency of the grid connection.
Gradient	0 ... 100 %	This feature adjusts the gradient. The units are % / Hz.
Recovery Time		Not applicable for LVD or MVD
Mode	ON   OFF	Switches the feature on and off

6.3.6.3.3 Constant cos  $\varphi$

This feature is available for LVD and MVD grids. This feature allows the user to set up a constant COS  $\varphi$ .

Reactive Power Control		21. Jun 2011 13:50
cos $\varphi$	[ Ind 0.90 ]	
Mode	[ ON ]	

Figure 6.22.: Constant cos  $\varphi$  settings page

Adjustable parameters

Parameter	Adjustable values	Description
cos $\varphi$	inductive   capacitive Ind 0.8 ... Ind 0.99, 1, Cap 0.8 ... Cap. 0.99	Sets the cos $\varphi$ to the adjusted value.
Mode	ON   OFF	Switches the feature on and off

6.3.6.3.4 cos $\varphi$ (P)

This feature is available for LVD and MVD grids.

With this feature a cos  $\varphi$  can be assigned to a power ratio P/Pn.

The following curve is an example how the values could be set:

**Reactive Power Control** 21. Jun 2010 13:50
 

**a** Upper limit -  $\cos\phi$ 
[ Cap 0.90 ]

**b** Lower Power
[ 0 ] %

---

**c** Lower limit -  $\cos\phi$ 
[ Ind 0.90 ]

**d** Upper Power
[ 100 ] %

---


Lock-in Voltage
[ -- ] V

⬇ ⬆ ⬇

**Reactive Power Control** 21. Jun 2010 13:50
 

Lock-out Voltage
[ -- ] V

Mode
[ OFF ]


 Figure 6.23.:  $\cos\phi(P)$  settings page

### Adjustable parameters

Parameter	Adjustable values	Description
Upper limit - $\cos\phi$	Ind 0.80 ... Cap 0.80	The upper limit $\cos\phi$ must be greater than the lower limit $\cos\phi$
Lower Power	0 ... 100 %	
Lower limit - $\cos\phi$	Ind 0.80 ... Cap 0.80	
Upper Power	0 ... 100 %	The upper power must be greater than the lower power
Lock-in Voltage		Not used for DE LVD/MVD
Lock-out Voltage		Not used for DE LVD/MVD
Mode	ON I OFF	This switches the feature on and off

#### 6.3.6.3.5 Constant Reactive Power

This feature is available for MVD grids only.

This feature allows a constant  $\cos$  reactive power to be set.

Reactive Power Control		21. Jun 2011 13:50
Reactive Power (Q/Sn)	[ Cap 30 ] %	
Mode	[ OFF ]	

Figure 6.24.: Constant Reactive Power settings page


Adjustable parameters

Parameter	Adjustable values	Description
Reactive power Q/Sn	-60 ... +60% inductive   capacitive	Reactive power ratio in relation to apparent power.
Mode	ON   OFF	This switches the feature on and off

6.3.6.3.6 Q(V)

This feature is available for MVD grids only.

This feature allows the reactive power ratio Q/Sn to be assigned to a voltage V








Figure 6.25.: Q(V) settings page


### Adjustable parameters

Parameter	Menu Name	Adjustable values	Description
Lower Q/Sn	Qi Limit	0 ... 60% inductive   capacitive	Must be within the range Ind 60% ... Cap 60%
Upper Q/Sn	Qs Limit	0 ... 60% inductive   capacitive	Must be within the range Ind 60% ... Cap 60%
Lower capaci- tive point	V2i	184 ... 264 V	
Upper capaci- tive point	V1i	184 ... 264 V	For DE MVD the default V1i = V1s = 230 V
Lower inductive point	V1s	184 ... 264 V	
Upper inductive point	V2s	184 ... 264 V	
Delay time		0 ... 10 s	
Lock-in Power		not applicable	Not used for DE MVD
Lock-out Power		not applicable	Not used for DE MVD
Mode		ON   OFF	This switches the feature on and off

#### 6.3.6.3.7 Fault Ride Through (FRT)

This feature is available for MVD grids only.

This feature allows the Fault Ride Through features to be set.



- ① No instability or disconnection from the network
- ② Feed-in reactive current depends on K factor
- ③ Same as area 2, Feed-in reactive current depends on K factor
- ④ Disconnects from the network

FRT - 1/2		21. Jun 2011 13:50	
Dead band - Vh	[ +10 ]	%	
Dead band - Vl	[ -10 ]	%	
K factor	[ 2.0 ]		
Vdrop	[ 0 ]	%	
t1	[ 200 ]	ms	
U1	[ 20 ]	%	
t2	[ 3.00 ]	s	

⚡

→

⚡

FRT - 2/2		21. Jun 2011 13:50	
t3	[ 3.00 ]	s	
Mode	[ ON ]		

Figure 6.26.: Fault Ride Through settings page


**Adjustable parameters**

Parameter	Adjustable values	Description
Dead band - V <sub>high</sub>	+0 ... +20 %	
Dead band - V <sub>low</sub>	-20 ... 0 %	
K factor	0 ... 10	
V <sub>drop</sub>	0 ... 90%	
t <sub>1</sub>	0 ... 500 ms	
U <sub>1</sub>	20 ... 90%	
t <sub>2</sub>	0.01 ... 5 s	
t <sub>3</sub>	0.01 ... 5 s	
Mode	ON   OFF	This switches the feature on and off

**6.3.6.4 Active/Reactive Power control for Italy CEI 0-21 and Italy A70**

Below is an overview of the features that are adjustable to control the production of active and reactive power for Italy CEI 0-21 and Italy A70. Italy CEI 0-21 is applicable for low voltage grids and A70 is applicable for medium voltage grids.

Feature	Available for		Description
	CEI 0-21	A70	
Active power control			
Power limit	x	x	To reduce the maximum power production
Power vs. frequency	x	x	To set the power gradient in dependency of the frequency
Reactive power control			
Constant $\cos \varphi$			This feature is not available for CEI 0-21 and A70.
$\cos \varphi$ (p)	x	x	To set a $\cos \varphi$ (inductive or capacitive) in dependency of the active power ratio $P/P_n$
Constant reactive power	x	x	To set the reactive power ratio $Q/S_n$ .
Q (V)	x	x	To set the reactive power ratio $Q/S_n$ in dependency of the voltage V.




Note: User can activate both the Power Limit and the Power vs. Frequency at the same time.

For the reactive power control features:  $\cos\phi(P)$ , Constant Reactive Power, and  $Q(V)$  only one of these items can be activated at a time.

✓ indicates a function is executing


\* This feature is disabled for CEI 0-21 and A70 although it will appear in the menu

Figure 6.27.: Active/Reactive Power settings page



Note: Before adjusting the Active/Reactive Power settings, a Warning window will be displayed, that you should read and make a selection to continue or to quit. Please see caution messages related to adjusting the settings.

**CAUTION**



**Machine and equipment damage may occur.**

- ▶ Please only adjust active and reactive power settings if you are a qualified electrical technician with the knowledge to do so
- ▶ Adjustments may affect energy production
- ▶ Some values entered in the Active/Reactive Power settings must come from the local grid operator. Please check with them before making any adjustments

6.3.6.4.1 Power Limit

User can select set percentage of actual or rated power to limit inverter's output power. Inverter will start the action once the user sets the Mode to "ON". This feature is available for Italy CEI 0-21 and Italy A70.

Active Power Control		21. Jun 2010 13:50
Set Point	[ 100 ]	%
Actual/Rated Power	[ Rated ]	
Mode	[ OFF ]	

Note: For explanation of Actual vs Rated Power please see figure 6.18.

Figure 6.28.: Power Limit settings page

### Adjustable parameters

Parameter	Adjustable Values	Description
Set point	0 ... 100%	Sets the power reduction to the adjusted value. The value is multiplied with the value of the Locked power limitation.
Actual/Rated	Actual   Rated	Select Actual or Rated Power
Mode	ON   OFF	Switches the feature on and off.

#### 6.3.6.4.2 Power vs. Frequency

This function is available for CEI 0-21 and A70. The figure below explain the behavior of this function. Note that the Italy CEI 0-21 and A70 curves are different than the Germany LVD and MVD curves.

This feature allows the user to set a power reduction in a percent of the maximum power.





Figure 6.29.: Curve power vs. frequency

Active Power Control		21. Jun 2010 13:50
a Actual/Rated Power	[ Actual ]	
b Start Frequency	[ 50.30 ] Hz	
c Stop Frequency	[ -- ] Hz	
d Recovery Frequency	[ -- ] Hz	
e Gradient	[ 2.4 ] %	
Recovery Time	[ 300.00 ] s	
Mode	[ ON ]	

**NOTE**



The Power vs Frequency function is required for CEI 0-21 and A70. Please make sure the Mode is ON and do not turn off.

\*Recovery Frequency is defined in the grid setting parameters 49.9 - 50.1 Hz by default.

Figure 6.30.: Power vs. Frequency

Adjustable parameters

Parameter	Adjustable Values	Description
Actual / Rated Power		Actual will be default
Start frequency	50 - 55 Hz	50.3 Hz will be the default. This is the frequency when the power reduction starts
Stop frequency		Stop frequency means the frequency when power = 0. This value is calculated by the gradient and the start frequency.

Recovery frequency	Nonadjustable	
Gradient	2.0 ... 5.0 %	2.4 % is the default
Recovery time	300 seconds	
Mode	ON   OFF	Switches the feature on and off

#### 6.3.6.4.3 Constant $\cos\phi$

This feature is not available for CEI 0-21 or A70.

#### 6.3.6.4.4 $\cos\phi(P)$

This feature is available for Italy CEI 0-21 and Italy A70.

With this feature a solar inverter can regulate the power factor as a function of the actual delivered active power.

The following graph is an example how the values could be set:




Figure 6.31.:  $\cos\phi(P)$  graph

There are two possible curves defined in the  $\cos\phi(P)$  graph, curve A in blue (the default) and curve B in red.  $P_n$  = nominal power

##### Curve A (in blue on Figure 6.30)

A is identified from Plock-out = value from local grid operator and  $\cos\phi = 1$

B is identified from Plock-in = value from local grid operator and  $\cos\phi = 1$

C is identified from  $P = P_n$  and  $\cos = \cos\phi_{\max}$

##### Curve B (in red on Figure 6.30)


A is identified from Plock-out =  $P =$  value from local grid operator and  $\cos\phi = 1$

B is identified from Plock-in = value from local grid operator and  $\cos\phi = 1$

C is identified from  $P = P_n$  and  $\cos = \cos\phi_{\max}$

**Important:**

When Plock-out = Plock-in then Curve B will be followed.  
When Plock-out is  $\neq$  Plock-in then Curve A will be followed.



**Notes:**

In the formulas on the previous page, the parameters mentioned are named differently as in the menu page

**Curve A (in blue) Figure 6.30**

Point A = Plockout = Lower Power

Point B = Plockin = Upper Power

Point C = Lower limit  $\cdot \cos\phi$

Curve A is followed when Lower Power is not equal to Upper Power

**Curve B (in Red) Figure 6.30**

Point A (Lower Power) = Point B (Upper Power)

Point C = Lower limit  $\cdot \cos\phi$

Curve B is followed when Lower Power = Upper Power

Figure 6.32.:  $\cos\phi(P)$  settings page

**Adjustable parameters for  $\cos\phi(P)$**

Parameter	Adjustable values	Curve A	Curve B
Upper limit - $\cos\phi$	Ind 0.80 ... Cap 0.80	Cap 1.0	Cap 1.0
Lower Power	0 ... 100 %	45% is shown but adjust to grid operator requested value	should equal Upper Power
Lower limit - $\cos\phi$	Ind 0.80 ... Cap 0.80	Ind 0.90	Ind 0.90
Upper Power	0 ... 100 %	90% is shown but adjust to grid operator requested value	should equal Lower Power



## Operating the PV inverter

Parameter	Adjustable values	Curve A	Curve B
Lock-in Voltage*	230-253 V	241.5 V is default value and is $1.05V_n$ ( $V_n = 230V$ )	
Lock-out Voltage*	207-230 V	230 V is default value (adjustable at $0.98 V_n$ to $V_n$ ; $V_n=230V$ ). When the grid voltage $\leq$ the Lock-out voltage	
Mode	ON   OFF	This switches the feature on and off. Default mode is OFF.	

\*These values are only adjustable if Country setting is Italy CEI-021 or Italy A70. This means the inverter will feed in reactive power depending on the active power once the grid voltage is higher than Lock-in Voltage. When grid voltage is lower than Lock-out voltage then inverter would go back to pure active power control.

For countries other than Italy,  $\cos \phi(P)$  control would not be effected by the grid voltage.

#### 6.3.6.4.5 Constant Reactive Power

This feature is available for Italy CEI 0-21 and Italy A70.

This feature allows a constant  $\cos$  reactive power to be set.

Reactive Power Control		21. Jun 2010 13:50
Reactive Power (Q/Sn)	[ 0 ]	%
Mode	[ OFF ]	

Figure 6.33.: Constant Reactive Power settings page

#### Adjustable parameters

Parameter	Adjustable values	Description
Reactive power Q/Sn	-60 ... +60% inductive   capacitive	Reactive power ratio in relation to apparent power. Enter the value requested by the grid operator
Mode	ON   OFF	This switches the feature on and off

#### 6.3.6.4.6 Q(V)

This feature is available for Italy CEI 0-21 and Italy A70.

Operating the PV inverter

This feature allows the reactive power ratio  $Q/S_n$  to be assigned to a voltage  $V$ .





Figure 6.34.:  $Q(V)$

Reactive Power Control		21. Jun 2010 13:50
a	V1s	[ 248.4 ] V
b	V2s	[ 253.0 ] V
c	Qs limit	[ Ind 44 ] %
d	V1i	[ 211.6 ] V
e	V2i	[ 207.0 ] V
f	Qi limit	[ Cap 44 ] %

Note:  $Q_s$  limit and  $Q_i$  limit are calculated based on  $Q/S_n$ .



Reactive Power Control		21. Jun 2010 13:50
Delay Time	[ 10 ]	s
Lock-in Power	[ 20 ]	%
Lock-out Power	[ 5 ]	%
Mode	[ OFF ]	
		[OFF] [Curve A] [Curve B]

Figure 6.35.:  $Q(V)$  Settings Page

### Adjustable parameters

Parameter	Adjustable values	Description
Qs limit (Q/Sn)	0 ... 60% inductive   capacitive	Ind 44%
Qi limit (Q/Sn)	0 ... 60% inductive   capacitive	Cap 44%
V1s	230 ... 264.5 V	248.4 V
V2s	230 ... 264.5 V	253 V
V1i	184 ... 230 V	211.6 V
V2i	184 ... 230 V	207 V
Plock-in*	10 ... 100%	20% is shown but use value from the grid operator
Plock-out*	5 ... 10%	5% is shown but use value from the grid operator
Delay time	0 ... 120 s	10 s
Mode	Curve A   Curve B   OFF	This switches between Curve A and Curve B or OFF

\*This item is only adjustable and enabled if Country settings is Italy CEI 0-21 or Italy A70.

#### 6.3.6.4.7 LVFRT Low Voltage Fault Ride Through (LVFRT)

This feature is available for CEI 0-21 and A70.

This feature allows the Fault Ride Through features to be set.




Figure 6.36.: Low Voltage Fault Ride Through graph




Figure 6.37.: Fault Ride Through settings page

Adjustable parameters

Parameter	Adjustable values	Description
Dead band - Vhigh	+0 ... +20 %	10%
Dead band - Vlow	-20 ... 0 %	-15%
K factor	Do not adjust	
Vdrop	Do not adjust	
t1	Do not adjust	
U1	Do not adjust	
t2	Do not adjust	
t3	Do not adjust	
Mode	ON   OFF	This switches the feature ON and OFF

## 7. Maintenance

In order to ensure the normal operation of the PV Inverter, please check it regularly at least once every 6 months. Check that all the terminals, screws, cables are securely in place. If there are any damaged parts, please contact a qualified technician to repair it or to replace it with a new spare part. To ensure that no foreign contaminants enter the warm air outlets, please have them cleaned every 6 months by qualified technicians.



### WARNING



#### Death and serious injury may occur!

- Before engaging in maintenance of the inverter, please disconnect AC and DC power to avoid risk of electric shock.!

### 7.1 Cleaning the Fans

Loosen the 4 screws in the four corners of the fan bracket first (circled below). Pulling the bracket slightly away from the inverter, the user will notice 4 sets of fan connectors. Disconnect the fan connectors one by one and then pull the fan bracket from the inverter for cleaning. Call the support hotline for assistance in procuring a new replacement fan.




Figure 7.1.: Steps of removing the fan bracket from the inverter

## 7.2 Replace a Fan

If one of the fans has failed and needs to be replaced, user should remove the 4 screws (circled below) that attach the fan to the fan bracket. Next, pull the fan slightly away from the bracket and disconnect the fan connector located behind the fan bracket. The fan can now be removed and replaced with a new fan. Follow the procedure in reverse to install the new fan. (Figure 7-2 illustrates the replacement of the first fan on the fan bracket. Call the support hotline for assistance in procuring a replacement fan.




Figure 7.2.: Removing the fan from the fan bracket

## 7.3 Cleaning the Air Outlets

Figure 7.3 below shows the removal of the vent covers for cleaning. First remove the 4 screws that hold the vent cover to the inverter enclosure. Next, remove the vent cover from the inverter. With the vent cover removed, clean it on both sides. After cleaning one of the vents, proceed to take off the vent on the opposite side and clean in the same manner. Reinstall the vent covers securely after they have been cleaned. The cleaning of the air outlets as described above should be done on a regular basis for optimum inverter performance.




Figure 7.3.: Removing the Vent Covers for Cleaning



# 8. Measurements and Messages

## 8.1 Measurements




Figure 8.1.: Measurements on the Home Page

	Measurement	Description
A	E-Today	Total energy generated today
B	Runtime	Total PV inverter operation time for the day
C	Power	Actual power being generated

Table 8.1.: Home Page Measurements and Description




Figure 8.2.: Measurements on the Power Meter Pages

Measurement		Description
A	Input 1 P	Power of DC Input 1
B	Input 1 V	Voltage of DC input 1
C	Input 1 I	Current of DC input 1
D	Input 2 P	Power of DC input 2
E	Input 2 V	Voltage of DC input 2
F	Input 2 I	Current of DC input 2
G	Output P	Power of AC Output
H	Output V	Voltage of AC Output
I	Output I	Current of AC Output
J	Today Energy	Total accumulated electricity generated for the day
K	Today Runtime	Total accumulated operation time for the day
L	Total CO2 saved	Total accumulated CO2 emissions retrenched to present time
M	Today Earning	Total accumulated Euro amount earned for the day

Table 8.2.: Power Meter Pages Measurements and Description




Figure 8.3.: Measurements on the Statistics Pages

Measurement	Description
A E-Year	Total accumulated electricity generated in a year
B Peak Month	The peak month of electricity generated in the past year
C Year CO2 saved	Total accumulated CO2 emissions retrenched in a year
D E-Month	Total accumulated electricity generated in a month
E Peak Day	The peak day of electricity generated in the past month
F Month CO2 saved	Total accumulated CO2 emission retrenched in a month
G E-Day	Total accumulated electricity generated in a day
H Peak Hours	The peak hour of electricity generated in the past day
I Day CO2 saved	Total accumulated CO2 emission retrenched for a day

Table 8.3.: Statistics Pages Measurements and Description




Figure 8.4.: Measurements on the Actual Data Pages

Measurement	Description
A Input 1 Volt. maximum	The maximum DC input 1 voltage
B Input 1 I maximum	The maximum DC input 1 current
C Input 1 P maximum	The maximum DC input 1 power
D Input 2 Volt. maximum	The maximum DC input 2 voltage
E Input 2 I maximum	The maximum DC input 2 current
F Input 2 P maximum	The maximum DC input 2 power
G L1 Volt. maximum	The maximum AC L1 phase voltage
H L1 I maximum	The maximum AC L1 phase current
I L1 P maximum	The maximum AC L1 phase power
J L2 Volt maximum	The maximum AC L2 phase voltage
K L2 I maximum	The maximum AC L2 phase current
L L2 P maximum	The maximum AC L2 phase power
M L3 Volt. maximum	The maximum AC L3 phase voltage
N L3 I maximum	The maximum AC L3 phase current
O L3 P maximum	The maximum AC L3 phase power
P Output Volt. maximum	The maximum AC 3 phase voltage
Q Output I maximum	The maximum AC 3 phase current
R Output P maximum	The maximum AC 3 phase power

Table 8.4.: Actual Data Pages Measurement and Description

Actual Data - 4/4		21. Jun 2011 13:50	
Temperature		Max.	Min.
Inside	(°C)	<b>A</b> 59.3	15.7 <b>B</b>
Heatsink - 1	(°C)	<b>C</b> 75.5	15.3 <b>D</b>
Heatsink - 2	(°C)	<b>E</b> 74.2	15.2 <b>F</b>
Heatsink - 3	(°C)	<b>G</b> 73.6	15.2 <b>H</b>

Figure 8.5.: Measurements of Temperature on the Actual Data Pages

Temperature		
A	Inside max.	The maximum inverter inner temperature value
B	Inside min.	The minimum inverter inner temperature value
C	Heatsink-1 max.	The maximum Heatsink-1 temperature value
D	Heatsink-1 min.	The minimum Heatsink-1 temperature value
E	Heatsink-2 max.	The maximum Heatsink-2 temperature value
F	Heatsink-2 min.	The minimum Heatsink-2 temperature value
G	Heatsink-3 max.	The maximum Heatsink-3 temperature value
H	Heatsink-3 min.	The minimum Heatsink-3 temperature value

Table 8.5.: Temperature Measurement and Description

## 8.2 Messages

Message	Red LED on	Red LED blinks	Description
<b>Errors</b>			
AC Freq High	X		Grid frequency is over rating
AC Freq Low	X		Grid frequency is under rating
Grid Quality	X		Poor grid quality
HW Connect Fail	X		Can't detect grid sequence
No Grid	X		Grid voltage < 100V
AC Volt Low	X		Phase-L1, L2, or L3 voltage is under rating
AC Volt High	X		Phase-L1, L2, or L3 voltage is over rating
Solar1 High	X		DC1 voltage > 1000V
Solar2 High	X		DC2 voltage > 1000V
<b>Faults</b>			
HW DC Injection	X		DC injection is over rating
Temperature	X		Ambient, heatsink, or choke temperature is higher or lower than the normal operation range
HW NTC1 Fail	X		Temperature sensor 1 has failed
HW NTC2 Fail	X		Temperature sensor 2 has failed
HW NTC3 Fail	X		Temperature sensor 3 has failed
HW NTC4 Fail	X		Temperature sensor 4 has failed
Firmware Fail	X		Firmware is incompatible
HW DSP ADC1	X		DSP A/D failure – Vgrid or lout
HW DSP ADC2	X		DSP A/D failure – Vin or Vbus
HW DSP ADC3	X		DSP A/D failure – lin or lboost
HW Red ADC1	X		Red. A/D failure – Vgrid or Vinv
HW Red ADC2	X		Red. A/D failure – lout_dc
HW Efficiency	X		Efficiency is abnormal
HW COMM2	X		Can't communicate with Red. CPU
HW COMM1	X		Can't communicate with DSP
Ground Current	X		Residual current is over rating
Insulation	X		Array insulation has failed
HW Connected Fail	X		AC internal wire is disconnected
RCMU Fail	X		HW RCMU failure
Relay Test Short	X		One or more relays are defective - short

## Measurements and Messages

Message	Red LED on	Red LED blinks	Description
Relay Test Open	X		One or more relays are defective - open
Bus Unbalance	X		Bus voltage is unbalanced
HW Bus OVR	X		BUS or BUS+ or BUS- voltage is over rating
HW Bus UVR	X		BUS+ or BUS- voltage is under rating
AC Current High	X		Phase-L1, L2, or L3 current is over rating
HW CT A Fail	X		Current sensor-L1 failure
HW CT B Fail	X		Current sensor-L2 failure
HW CT C Fail	X		Current sensor-L3 failure
HW AC OCR	X		Output current is over hardware limit
Inverter Failure	X		Inverter Failure
HW ZC Fail	X		HW zero-crossing circuit failure
DC Current High	X		DC1 or DC2 current is over rating
<b>Warnings</b>			
HW FAN		X	Fan is locked or failed during operation
Solar1 Low		X	DC1 voltage is under rating
Solar2 Low		X	DC2 voltage is under rating

## 9. Troubleshooting




Figure 9.6.: LED Indicator

Message	Red LED on	Red LED blinks	Solution
<b>Errors</b>			
AC Freq High	X		<ul style="list-style-type: none"><li>▶ Check grid frequency on the inverter terminal</li><li>▶ Check the country setting</li></ul>
AC Freq Low	X		<ul style="list-style-type: none"><li>▶ Check grid frequency on the inverter terminal</li><li>▶ Check the country setting</li></ul>
Grid Quality	X		<ul style="list-style-type: none"><li>▶ Check the harmonics of the grid voltage</li><li>▶ Grid connection of the inverter may need to be further away from a non-linear load.</li></ul>



Message	Red LED on	Red LED blinks	Solution
HW Connect Fail	X		<ul style="list-style-type: none"> <li>▶ Check the AC connection, must be according to the manual instructions</li> <li>▶ Please contact your installation technician or DELTA technical support</li> </ul>
No Grid	X		<ul style="list-style-type: none"> <li>▶ Check the connection of the AC plug, ensure it is connected to the inverter and the AC breaker is on</li> </ul>
AC Volt Low	X		<ul style="list-style-type: none"> <li>▶ Check the utility voltage connection to the inverter terminal</li> <li>▶ Check the country setting</li> </ul>
AC Volt High	X		<ul style="list-style-type: none"> <li>▶ Check the utility voltage connection to the inverter terminal</li> <li>▶ Check the country setting</li> </ul>
Solar1 High	X		<ul style="list-style-type: none"> <li>▶ Modify the solar array setting and make the Voc less than 1000 Vdc</li> </ul>
Solar2 High	X		<ul style="list-style-type: none"> <li>▶ Modify the solar array setting and make the Voc less than 1000 Vdc</li> </ul>
<b>Faults</b>			
HW DC Injection	X		<ul style="list-style-type: none"> <li>▶ Check the utility waveform. Grid connection of the inverter may need to be further from the non-linear load.</li> <li>▶ Please contact your installation technician or DELTA technical support</li> </ul>
Temperature	X		<ul style="list-style-type: none"> <li>▶ Check the installation ambient and environment</li> </ul>
HW NTC1 Fail	X		<ul style="list-style-type: none"> <li>▶ Please contact your installation technician or DELTA technical support</li> </ul>
HW NTC2 Fail	X		<ul style="list-style-type: none"> <li>▶ Please contact your installation technician or DELTA technical support</li> </ul>
HW NTC3 Fail	X		<ul style="list-style-type: none"> <li>▶ Please contact your installation technician or DELTA technical support</li> </ul>
HW NTC4 Fail	X		<ul style="list-style-type: none"> <li>▶ Please contact your installation technician or DELTA technical support</li> </ul>
Firmware Fail	X		<ul style="list-style-type: none"> <li>▶ Please contact your installation technician or DELTA technical support</li> </ul>
HW DSP ADC1	X		<ul style="list-style-type: none"> <li>▶ Please contact your installation technician or DELTA technical support</li> </ul>
HW DSP ADC2	X		<ul style="list-style-type: none"> <li>▶ Please contact your installation technician or DELTA technical support</li> </ul>
HW DSP ADC3	X		<ul style="list-style-type: none"> <li>▶ Please contact your installation technician or DELTA tech. support</li> </ul>
HW Red ADC1	X		<ul style="list-style-type: none"> <li>▶ Please contact your installation technician or DELTA tech. support</li> </ul>

## Troubleshooting

Message	Red LED on	Red LED blinks	Solution
HW Red ADC2	X	►	Please contact your installation technician or DELTA tech. support
HW Efficiency	X	►	Please contact your installation technician or DELTA technical support
HW COMM2	X	►	Please contact your installation technician or DELTA technical support
HW COMM1	X	►	Please contact your installation technician or DELTA technical support
Ground Current	X	► ► ►	Check the insulation of Solar inputs Check the capacitance ( +<-> GND & - <-> GND), must be < 2.5 $\mu$ F. Install an external transformer if necessary Please contact your installation technician or DELTA technical support
Insulation	X	► ► ►	Check the insulation of solar inputs Check the capacitance, dry the PV panel if necessary Please contact your installation technician or DELTA technical support
HW Connected Fail	X	►	Please contact your installation technician or DELTA technical support
RCMU Fail	X	►	Please contact your installation technician or DELTA technical support
Relay Test Short	X	►	Please contact your installation technician or DELTA technical support
Relay Test Open	X	►	Please contact your installation technician or DELTA technical support
Bus Unbalance	X	► ► ►	Check the inputs connections Check the PV Array insulation Please contact your installation technician or DELTA technical support
HW Bus OVR	X	► ► ► ►	Check the inputs connections Check the PV Array insulation Please contact your installation technician or DELTA technical support Modify the solar array setting and make the Voc less than 1000 Vdc
AC Current High	X	►	Please contact your installation technician or DELTA technical support if it will not go back to normal operation
HW CT A Fail	X	►	Please contact your installation technician or DELTA technical support if it will not go back to normal operation

Message	Red LED on	Red LED blinks	Solution
HW CT B Fail	X		► Please contact your installation technician or DELTA technical support if it will not go back to normal operation
HW CT C Fail	X		► Please contact your installation technician or DELTA technical support if it will not go back to normal operation
HW AC OCR	X		► Please contact your installation technician or DELTA technical support if it will not go back to normal operation
Inverter Failure	X		► Please contact your installation technician or DELTA technical support if it will not go back to normal operation
HW ZC Fail	X		► Please contact your installation technician or DELTA technical support
DC Current High	X		► Please contact your installation technician or DELTA technical support if it will not go back to normal operation
<b>Warnings</b>			
HW FAN		X	► Remove the object that is stuck in the fan(s) ► Replace the defective fan(s) ► Check the connections of all fans
Solar 1 Low		X	► Check the DC1 voltage connection to the inverter terminal ► Check all switching devices in boost1
Solar 2 Low		X	► Check the DC2 voltage connection to the inverter terminal ► Check all switching devices in boost2

Table 9.1.: Troubleshooting Message/Solution Description

## 10. Decommissioning

### Decommissioning Procedure

If it is necessary to put the SOLIVIA 15 TL / 20 TL out of operation for return or maintenance, please follow the instructions below:



### WARNING



**Death and serious injury may occur.**

To avoid injuries, please follow the below procedures:

1. Switch off AC circuit breaker to disconnect with electrical grid.
  2. Switch off the DC Disconnect switch to disconnect with DC power input.
  3. Use the proper voltage meter to confirm that the AC and DC power connections are void of any current.
  4. Remove the AC wiring immediately to completely disconnect with electrical grid.
  5. Remove the DC wiring to disconnect with PV array.
  6. Remove the Communication module RS485 with the computer connection.
  7. After finishing all the procedures, you can remove the SOLIVIA 15 TL / 20 TL from the mounting bracket.
-

## 11. Technical data

### 11.1 Specification

#### NOTE



The specification is subject to change. Please check the web site at [www.solar-inverter.com](http://www.solar-inverter.com) for the latest version.

	15EUG4TL	20EUG4TL
<b>INPUT (DC)</b>		
Max. recommended PV power	19 kW <sub>P</sub>	25 kW <sub>P</sub>
Recommended PV power range	14 ... 19 kW <sub>P</sub>	18 ... 25 kW <sub>P</sub>
Nominal power	15.3 kW	20.4 kW
Operating voltage	250 ... 1000 V <sub>DC</sub>	
MPP voltage range @ nominal power	350 ... 800 V <sub>DC</sub>	
Nominal voltage	630 V <sub>DC</sub>	
Start up power	40 W	
Absolute maximum voltage	1000 V	
Number of inputs	4 inputs (2 MPP trackers)	
Max. current	48 A (24 A x 2)	60 A (30 A x 2)
<b>OUTPUT (AC)</b>		
Max. apparent power <sup>1)</sup>	15.75 kVA	21.0 kVA
Nominal apparent power	15.0 kVA	20.0 kVA
Voltage range (3 phase) <sup>2)</sup>	230 / 400 V <sub>AC</sub> (3-Phase + N + PE)*	
Nominal current	22 A	29 A
Max. current	25 A	32 A
Nominal frequency	50/60 Hz	
Frequency range <sup>2)</sup>	50 Hz: 45 ... 55 Hz, 60 Hz: 55 ... 65 Hz	
Power factor	Cap 0.80 - Ind 0.80	
Total harmonic distortion	< 3 % @ nominal apparent power	
DC current injection	< 0.5 % rated current	
Night-time loss	< 2 W	
<b>GENERAL SPECIFICATION</b>		
Maximum efficiency	98.0 % for 15 TL and 20 TL	
EU efficiency	97.8 % for 15 TL and 20 TL	
Operating temperature	-20 - +60° C (Derating at 40 - 60° C)	
Storage temperature	-20 - +70° C	
Humidity	0 - 90 %	

## Technical data

	15EUG4TL	20EUG4TL
Max. Operating Altitude	2000 m	
<b>MECHANICAL DESIGN</b>		
Size (L x W x D)	952 x 625 x 275 mm	
Weight	67.2 kg	67.2 kg
Enclosure	Powder coated aluminum	
Cooling	Fan	
AC connector	Amphenol C16-3	
DC connector pairs	4 Multicontact MC4	
Communication interfaces	2 RJ45 / RS485	
DC disconnect	Integrated	
Display	Black / white graphical LCD	
<b>STANDARDS / DIRECTIVES</b>		
Protection degree <sup>3)</sup>	IP55 lower section / IP65 upper section (see figure 4-1 for further detail)	
Safety class	1	
Configurable trip parameters	Yes	
Insulation monitoring	Yes	
Overload behavior	Current limitation, power limitation	
Safety	IEC62109-1 / -2, AS/NZS 3100	
Grid Interface	VDE-AR-N 4105, BDEW, VDE 0126-1-1; G59/2; EN 50438; UTE C15-712-1, Synergrid C10/C11 (fulfills C10/C11 transitional rule from June 2012), RD661, RD1699, CEI 0-21, TERNA A70, AS 4777	
EMC	EN61000-6-2; EN61000-6-3; EN61000-3-11; EN61000-3-12, C-Tick	

<sup>1)</sup> The maximum AC apparent power indicates the power an inverter is able to deliver. This maximum apparent power may not necessarily be reached.


<sup>2)</sup> AC voltage and frequency range will be programmed according to the individual country requirements.

<sup>3)</sup> IP55 for cooling section / IP65 for electronics

## 11.2 Cable Recommendations

<b>Power wiring</b>		
Current rating	Cross-section	Recommended max. cable loss calculation
AC 30 A	Calculated based on needed length, used material, cable losses and etc.	<1 %
DC 30 A	6 mm <sup>2</sup>	<1 %
<b>Communication cable</b>		
RS485 modular communication cable / cross wired 8 poles		

# 11.3 Earthing Systems




TN-S	TN-C	TN-C-S	TT	IT
Yes	Yes	Yes	Yes*	No

\* TT is **NOT** recommended. Have to ensure the voltage of N is very close to PE ( $< 20V_{rms}$ ).

Figure 11.1.: Earthing Systems

12. Certificates



BUREAU  
VERITAS

Bureau Veritas Consumer  
Products Services  
Germany GmbH  
Businesspark A&B  
Graf-Adolf-Strasse  
40629 Essen  
Germany  
+49 (0) 47 746 41 - 0  
cps-uk@bureauveritas.com

Certificate of compliance

Applicant:

Delta Energy Systems Germany GmbH  
Tschellinstraße 21  
79331 Tettingen  
Germany

Product:

Automatic disconnection device between a generator  
and the public low-voltage grid

Model:

SOLIVIA15EUG4TL; SOLIVIA20EUG4TL

Use in accordance with regulations:

Automatic disconnection device with three-phase mains surveillance in accordance with Engineering Recommendation G592 for photovoltaic systems with a three-phase parallel coupling via an inverter in the public mains supply. The automatic disconnection device is an integral part of the aforementioned inverter. This serves as a replacement for the disconnection device with isolating function that can access the distribution network provider at any time.

Applied rules and standards :

DIN VDE V 0126-1-1:2006-02 (Redundancy) and Engineering Recommendation G592: The default values for "Small Power Stations" on the low-voltage grid were verified.

The safety concept of an aforementioned representative product corresponds at the time of issue of this certificate of valid safety specifications for the specified use in accordance with regulations.

Report number:

11TH0291-G592\_Delfo

Certificate number:

U11-925

Date of issue:

2011-10-12

Valid until:

2014-10-11



Achim Hänchen



BUREAU  
VERITAS

Bureau Veritas Consumer  
Products Services  
Germany GmbH  
Businesspark A&B  
Graf-Adolf-Strasse  
40629 Essen  
Deutschland  
+49 (0) 47 746 41 - 0  
cps-uk@bureauveritas.com

Unbedenklichkeitsbescheinigung

Antragsteller:

Delta Energy Systems Germany GmbH  
Tschellinstraße 21  
79331 Tettingen  
Germany

Erzeugnis:

Selbsttätige Schaltstelle zwischen einer netzparallelen  
Eigenenergieanlage und dem öffentlichen  
Niederspannungsnetz

Modell:

SOLIVIA15EUG4TL; SOLIVIA20EUG4TL

Bestimmungsgemäße Verwendung:

Reisende Schaltstelle mit dreiphasiger Niederspannung gemäß DIN VDE V 0126-1-1:2006-02 für Photovoltaik-Systeme mit Parallelbetrieb. Die selbsttätige Schaltstelle ist integraler Bestandteil des oben angeführten traflosen Wechselrichter. Diese dient als Ersatz für eine jederzeit dem Verteilungsnetzbetreiber (VNB) zugängliche Schaltstelle mit Trennfunktion.

Prüfgrundlagen:

DIN VDE V 0126-1-1 (VDE V 0126-1-1:2006-02 und „Eigenenergieanlagen am Niederspannungsnetz, 4. Ausgabe 2001, Richtlinie für Anschluss und Parallelbetrieb von Eigenenergieanlagen am Niederspannungsnetz“ mit VDN Ergänzungen, Stand 2005 vom Verband der Elektrizitätswirtschaft (VDEW) und vom Verband der Netzbetreiber (VDN).

Ein repräsentatives Testmuster der oben genannten Erzeugnisse entspricht den zum Zeitpunkt der Ausstellung dieser Bescheinigung geltenden sicherheitstechnischen Anforderungen der aufgeführten Prüfgrundlagen für die bestimmungsgemäße Verwendung.

Bericht Nummer:

11TH0291-VDE0126

Zertifikat Nummer:


U11-693

Datum:

2011-08-17

Gültig bis:

2014-07-27



Achim Hänchen

92





Bureau Veritas Consumer  
Products Services  
Germany GmbH  
Businesspark A&B  
88942 Tübingen  
+49 (0) 49 749 41 - 0  
cps-kunden@bureauveritas.com



## Certificat de conformité

**Demandeur:** Delta Energy Systems Germany GmbH  
Tscheulinstraße 21  
79331 Teningen  
Allemagne

**Produit:** Dispositif de déconnexion automatique entre un  
générateur et le réseau public à basse tension

**Modèle:** SOLIVIA 15EUG4TL; SOLIVIA20EUG4TL

**A utiliser conformément aux réglementations:**  
Dispositif de coupure automatique avec une surveillance du réseau triphasé, conformément à C10/11 - 06/2006, appendice 3, pour des systèmes photovoltaïques avec un couplage parallèle triphasé, via un convertisseur de tension à alimentation électrique publique. Le dispositif de coupure automatique fait partie intégrante de ce convertisseur. Il remplace le appareil de déconnexion avec une fonction isolante, auquel le fournisseur du réseau de distribution peut accéder à tout moment.

### Réglementations et normes appliquées:

C10/11 - 06/2006  
DIN VDE V 0126-1-1:2006-02  
Un échantillon représentatif des produits mentionnés ci-dessus correspond à la date de la délivrance de ce certificat en vigueur des exigences de sécurité technique et pour l'utilisation conformément à sa destination.

**Numéro de rapport:** 11TH0291-C10-11\_Delta  
**Numéro de certificat:** U11-907  
**Délivre le:** 2011-10-04 **Valide jusque le:** 2014-10-03

Achim Hanchen



Bureau Veritas Consumer  
Products Services  
Germany GmbH  
Businesspark A&B  
88942 Tübingen  
+49 (0) 49 749 41 - 0  
cps-kunden@bureauveritas.com



## Certificat de conformité

**Solicitant:** Delta Energy Systems (Deutschland) GmbH  
Tscheulinstr. 21  
79331 Teningen  
Germany

**Produit:** Dispositif de déconnexion automatique entre générateur et  
réseaux de distribution publique de basse tension

**Modèle:** SOLIVIA15EUG4TL; SOLIVIA20EUG4TL

### A se utiliza în conformitate cu reglementările de mai jos:

Dispositiv de decupare automată a sistemului de supraveghere a curentului trifazic în conformitate cu C10/11 - 06/2006, anexa 3, pentru sisteme fotovoltaice cu cuplaj paralel trifazic, prin intermediul unui convertor de tensiune la alimentare cu energie electrică. Dispozitivul de decupare automată este parte integrantă a invertorului menționat anterior. Acesta servește drept înlocuitor al dispozitivului de decupare cu funcția de izolare, pe care furnizorul rețelei de distribuție îl poate orișând accesa.

### Reguli și standarde aplicabile:

DIN VDE V 0126-1-1 (VDE V 0126-1-1:2006-02 și „Generator în rețeaua de distribuție publică de joasă tensiune, ediția a patra, 2001, norme privind racordarea și funcționarea în parcul a generatorilor din rețeaua de distribuție publică de joasă tensiune” cu adăugirea VDN (2005) din partea Asociației Germane de Electricitate (VDEW) și a Asociației Operatorilor de Rețea (VDN).

Conceptul de siguranță al produsului reprezentativ susținutului corespunde, la momentul emiterii prezentului certificat, specificațiilor valide privind siguranța pentru utilizarea specificată în conformitate cu normele.

**Număr raport:** 11TH0291-VDE0126  
**Număr certificat:** U12-0192  
**Data emiterii:** 2012-03-16 **Valabil până la:** 2014-07-27

Achim Hanchen



Bureau Veritas Consumer  
Products Services  
Germany GmbH  
Businesspark A&B  
Friedrich-Koch-Str. 1  
40704 Erkrath  
Germany  
+49 (0) 40 740 41 - 0  
cpa.koch@bureauveritas.com

## Πιστοποιητικό ελλείψεως κωλυμάτων

Εντολοδότης:

Delta Energy Systems Germany GmbH  
Tschellinstraße 21  
79331 Teningen  
Γερμανία

Παρασώμενο προϊόν:

Ανεξάρτητη διασκευή μεταξύ μιας δικτυακής παράλληλης αυτοαποφορτιζόμενης εγκατάστασης και του δημόσιου δικτύου χαμηλής τάσης

Μοντέλο:

SOLIVIA15EUG4TL; SOLIVIA20EUG4TL

Προβλεπόμενη χρήση:

Ανεξάρτητη διασκευή επιτήρησης δικτύου σύμφωνα με το DIN V VDE V 0126-1-1:2006-02\* για δικτυακή παράλληλη εγκατάσταση με σκοπό την αποφόρτιση του δικτύου χαμηλής τάσης. Η ανεξάρτητη διασκευή είναι επιπρόσθετο εξάρτημα για τον προαναφερθέντα αναστολέα. Αυτοοργανίζεται εφόσον για την περίπτωση διαταγής ανάγκης στην εταιρεία δανομής δικτύου (εταιρεία ηλεκτρομολογίας) με λειτουργία απόδοσης.

ΔΕΙΞΤΕ ΤΟ ΔΕΛΤΙΟ ΕΛΕΓΧΟΥ  
RECEIVED 01.09.2011  
RECEIVED 01.09.2011

Βασικά στοιχεία ελέγχου:

DIN V VDE V 0126-1-1:2006-02 και „Οδηγία για σύνδεση και παράλληλη λειτουργία από δικτυακή παράλληλη εγκατάσταση σε δίκτυο χαμηλής τάσης της „Ένωσης ηλεκτροτεχνικών έργων Γερμανίας VDEW“.

Η ένωση της σφράγισης ενός προαναφερθέντος αντιπροσωπευτικού προϊόντος αποσφαλμάτσης της παρασκευής και της λειτουργίας του προϊόντος σύμφωνα με τους κανονισμούς ασφαλείας για τη συγκεκριμένη χρήση σύμφωνα με τους κανονισμούς.

Αριθμός αναφοράς: 11TH0291-VDE0126\_GRE\_DeTe

Αριθμός πιστοποίησης: U11-902

Ημερομηνία: 2011-09-30

Ισχύει μέχρι: 2014-09-29

Achim Hanchen



Bureau Veritas Consumer  
Products Services  
Germany GmbH  
Businesspark A&B  
Friedrich-Koch-Str. 1  
40704 Erkrath  
Düsseldorf  
+49 (0) 40 740 41 - 0  
cpa.koch@bureauveritas.com

## Verklaring van geen bezwaar

Aanvrager:

Delta Energy Systems Germany GmbH  
Tschellinstraße 21  
79331 Teningen  
Duitsland

Product:

Automatisch schakelstation tussen een netparallele zelfopwekinstallatie en het openbare laagspanningsnet

Model:

SOLIVIA15EUG4TL; SOLIVIA20EUG4TL

Reglementair voorgeschreven gebruik:

Automatisch schakelstation met drie fase netverbekking conform C1011 - 06:2006. Bijlage 3 voor fotovoltaïsche installaties met een drie fase parallelvoeding door middel van gelijkstroom-wisselstroomomvormer in het net van de openbare voorziening. Het automatische schakelstation vormt een integraal bestanddeel van de hoger vermeldde gelijkstroom-wisselstroomomvormers.

Controlbasis:

C1011 - 06:2006  
DIN V VDE V 0126-1-1:2006-02

Een representatief testpatroon van het hoger vermeldde product voldoet aan de op het moment van de uitlegging van dit attest geldende veiligheids technische eisen van de vermeldde controlgrondbeginselen voor een reglementair voorgeschreven gebruik.

Rapportnummer:

11TH0291-C1011\_DeTe

Certificaatnummer:

U11-905

Datum:

2011-10-04

Geldig tot:

2014-10-03

Achim Hanchen





Bureau Veritas Consumer  
Products Services  
Germany GmbH  
Businesspark A88  
Ludwig-Platz 1  
Düsseldorf  
+49 (0)40 740 41 - 0  
cps.kuehnem@bureauveritas.com

## Potvrzení o nezávadnosti

**Žadatel:** Delta Energy Systems Germany GmbH  
Tscheulinstraße 21  
Německo

**Výrobek:** Samostatná spínací stanice mezi síťovou paralelním vlastním výrobním zařízením a veřejnou sítí nízkého napětí.

**Model:** SOLIVIA15EUG4TL; SOLIVIA20EUG4TL

**Používání podle určení:** Spínací stanice nízkého napětí dle DIN V VDE V 0126-1-1:2006-02 (s ČR odpovídá podle EN 50438:2007, Annex A\*) pro leproučasná zařízení s třízovým paralelním napájením pomocí měničů do sítě veřejného napájení. Samostatná spínací stanice je integrována součástí výše uvedených beztransformátorových (trafidos) měničů. Tato slouží jako náhrada za spínací stanici s dělicí funkcí, která je kdykoli přístupná provozovateli rozvodné sítě (VNB).

49.5Hz-50.5Hz

### Zkušební podklady:

DIN VDE V 0126-1-1:2006-02, EN 50438:2007 a „Vlastní výroční zprávy“ u sítě nízkého napětí dle 2011, 2012, 2013, 2014, 2015, 2016, 2017, 2018, 2019, 2020, 2021, 2022, 2023, 2024, 2025, 2026, 2027, 2028, 2029, 2030, 2031, 2032, 2033, 2034, 2035, 2036, 2037, 2038, 2039, 2040, 2041, 2042, 2043, 2044, 2045, 2046, 2047, 2048, 2049, 2050, 2051, 2052, 2053, 2054, 2055, 2056, 2057, 2058, 2059, 2060, 2061, 2062, 2063, 2064, 2065, 2066, 2067, 2068, 2069, 2070, 2071, 2072, 2073, 2074, 2075, 2076, 2077, 2078, 2079, 2080, 2081, 2082, 2083, 2084, 2085, 2086, 2087, 2088, 2089, 2090, 2091, 2092, 2093, 2094, 2095, 2096, 2097, 2098, 2099, 2100, 2101, 2102, 2103, 2104, 2105, 2106, 2107, 2108, 2109, 2110, 2111, 2112, 2113, 2114, 2115, 2116, 2117, 2118, 2119, 2120, 2121, 2122, 2123, 2124, 2125, 2126, 2127, 2128, 2129, 2130, 2131, 2132, 2133, 2134, 2135, 2136, 2137, 2138, 2139, 2140, 2141, 2142, 2143, 2144, 2145, 2146, 2147, 2148, 2149, 2150, 2151, 2152, 2153, 2154, 2155, 2156, 2157, 2158, 2159, 2160, 2161, 2162, 2163, 2164, 2165, 2166, 2167, 2168, 2169, 2170, 2171, 2172, 2173, 2174, 2175, 2176, 2177, 2178, 2179, 2180, 2181, 2182, 2183, 2184, 2185, 2186, 2187, 2188, 2189, 2190, 2191, 2192, 2193, 2194, 2195, 2196, 2197, 2198, 2199, 2200, 2201, 2202, 2203, 2204, 2205, 2206, 2207, 2208, 2209, 2210, 2211, 2212, 2213, 2214, 2215, 2216, 2217, 2218, 2219, 2220, 2221, 2222, 2223, 2224, 2225, 2226, 2227, 2228, 2229, 2230, 2231, 2232, 2233, 2234, 2235, 2236, 2237, 2238, 2239, 2240, 2241, 2242, 2243, 2244, 2245, 2246, 2247, 2248, 2249, 2250, 2251, 2252, 2253, 2254, 2255, 2256, 2257, 2258, 2259, 2260, 2261, 2262, 2263, 2264, 2265, 2266, 2267, 2268, 2269, 2270, 2271, 2272, 2273, 2274, 2275, 2276, 2277, 2278, 2279, 2280, 2281, 2282, 2283, 2284, 2285, 2286, 2287, 2288, 2289, 2290, 2291, 2292, 2293, 2294, 2295, 2296, 2297, 2298, 2299, 2300, 2301, 2302, 2303, 2304, 2305, 2306, 2307, 2308, 2309, 2310, 2311, 2312, 2313, 2314, 2315, 2316, 2317, 2318, 2319, 2320, 2321, 2322, 2323, 2324, 2325, 2326, 2327, 2328, 2329, 2330, 2331, 2332, 2333, 2334, 2335, 2336, 2337, 2338, 2339, 2340, 2341, 2342, 2343, 2344, 2345, 2346, 2347, 2348, 2349, 2350, 2351, 2352, 2353, 2354, 2355, 2356, 2357, 2358, 2359, 2360, 2361, 2362, 2363, 2364, 2365, 2366, 2367, 2368, 2369, 2370, 2371, 2372, 2373, 2374, 2375, 2376, 2377, 2378, 2379, 2380, 2381, 2382, 2383, 2384, 2385, 2386, 2387, 2388, 2389, 2390, 2391, 2392, 2393, 2394, 2395, 2396, 2397, 2398, 2399, 2400, 2401, 2402, 2403, 2404, 2405, 2406, 2407, 2408, 2409, 2410, 2411, 2412, 2413, 2414, 2415, 2416, 2417, 2418, 2419, 2420, 2421, 2422, 2423, 2424, 2425, 2426, 2427, 2428, 2429, 2430, 2431, 2432, 2433, 2434, 2435, 2436, 2437, 2438, 2439, 2440, 2441, 2442, 2443, 2444, 2445, 2446, 2447, 2448, 2449, 2450, 2451, 2452, 2453, 2454, 2455, 2456, 2457, 2458, 2459, 2460, 2461, 2462, 2463, 2464, 2465, 2466, 2467, 2468, 2469, 2470, 2471, 2472, 2473, 2474, 2475, 2476, 2477, 2478, 2479, 2480, 2481, 2482, 2483, 2484, 2485, 2486, 2487, 2488, 2489, 2490, 2491, 2492, 2493, 2494, 2495, 2496, 2497, 2498, 2499, 2500, 2501, 2502, 2503, 2504, 2505, 2506, 2507, 2508, 2509, 2510, 2511, 2512, 2513, 2514, 2515, 2516, 2517, 2518, 2519, 2520, 2521, 2522, 2523, 2524, 2525, 2526, 2527, 2528, 2529, 2530, 2531, 2532, 2533, 2534, 2535, 2536, 2537, 2538, 2539, 2540, 2541, 2542, 2543, 2544, 2545, 2546, 2547, 2548, 2549, 2550, 2551, 2552, 2553, 2554, 2555, 2556, 2557, 2558, 2559, 2560, 2561, 2562, 2563, 2564, 2565, 2566, 2567, 2568, 2569, 2570, 2571, 2572, 2573, 2574, 2575, 2576, 2577, 2578, 2579, 2580, 2581, 2582, 2583, 2584, 2585, 2586, 2587, 2588, 2589, 2590, 2591, 2592, 2593, 2594, 2595, 2596, 2597, 2598, 2599, 2600, 2601, 2602, 2603, 2604, 2605, 2606, 2607, 2608, 2609, 2610, 2611, 2612, 2613, 2614, 2615, 2616, 2617, 2618, 2619, 2620, 2621, 2622, 2623, 2624, 2625, 2626, 2627, 2628, 2629, 2630, 2631, 2632, 2633, 2634, 2635, 2636, 2637, 2638, 2639, 2640, 2641, 2642, 2643, 2644, 2645, 2646, 2647, 2648, 2649, 2650, 2651, 2652, 2653, 2654, 2655, 2656, 2657, 2658, 2659, 2660, 2661, 2662, 2663, 2664, 2665, 2666, 2667, 2668, 2669, 2670, 2671, 2672, 2673, 2674, 2675, 2676, 2677, 2678, 2679, 2680, 2681, 2682, 2683, 2684, 2685, 2686, 2687, 2688, 2689, 2690, 2691, 2692, 2693, 2694, 2695, 2696, 2697, 2698, 2699, 2700, 2701, 2702, 2703, 2704, 2705, 2706, 2707, 2708, 2709, 2710, 2711, 2712, 2713, 2714, 2715, 2716, 2717, 2718, 2719, 2720, 2721, 2722, 2723, 2724, 2725, 2726, 2727, 2728, 2729, 2730, 2731, 2732, 2733, 2734, 2735, 2736, 2737, 2738, 2739, 2740, 2741, 2742, 2743, 2744, 2745, 2746, 2747, 2748, 2749, 2750, 2751, 2752, 2753, 2754, 2755, 2756, 2757, 2758, 2759, 2760, 2761, 2762, 2763, 2764, 2765, 2766, 2767, 2768, 2769, 2770, 2771, 2772, 2773, 2774, 2775, 2776, 2777, 2778, 2779, 2780, 2781, 2782, 2783, 2784, 2785, 2786, 2787, 2788, 2789, 2790, 2791, 2792, 2793, 2794, 2795, 2796, 2797, 2798, 2799, 2800, 2801, 2802, 2803, 2804, 2805, 2806, 2807, 2808, 2809, 2810, 2811, 2812, 2813, 2814, 2815, 2816, 2817, 2818, 2819, 2820, 2821, 2822, 2823, 2824, 2825, 2826, 2827, 2828, 2829, 2830, 2831, 2832, 2833, 2834, 2835, 2836, 2837, 2838, 2839, 2840, 2841, 2842, 2843, 2844, 2845, 2846, 2847, 2848, 2849, 2850, 2851, 2852, 2853, 2854, 2855, 2856, 2857, 2858, 2859, 2860, 2861, 2862, 2863, 2864, 2865, 2866, 2867, 2868, 2869, 2870, 2871, 2872, 2873, 2874, 2875, 2876, 2877, 2878, 2879, 2880, 2881, 2882, 2883, 2884, 2885, 2886, 2887, 2888, 2889, 2890, 2891, 2892, 2893, 2894, 2895, 2896, 2897, 2898, 2899, 2900, 2901, 2902, 2903, 2904, 2905, 2906, 2907, 2908, 2909, 2910, 2911, 2912, 2913, 2914, 2915, 2916, 2917, 2918, 2919, 2920, 2921, 2922, 2923, 2924, 2925, 2926, 2927, 2928, 2929, 2930, 2931, 2932, 2933, 2934, 2935, 2936, 2937, 2938, 2939, 2940, 2941, 2942, 2943, 2944, 2945, 2946, 2947, 2948, 2949, 2950, 2951, 2952, 2953, 2954, 2955, 2956, 2957, 2958, 2959, 2960, 2961, 2962, 2963, 2964, 2965, 2966, 2967, 2968, 2969, 2970, 2971, 2972, 2973, 2974, 2975, 2976, 2977, 2978, 2979, 2980, 2981, 2982, 2983, 2984, 2985, 2986, 2987, 2988, 2989, 2990, 2991, 2992, 2993, 2994, 2995, 2996, 2997, 2998, 2999, 3000, 3001, 3002, 3003, 3004, 3005, 3006, 3007, 3008, 3009, 3010, 3011, 3012, 3013, 3014, 3015, 3016, 3017, 3018, 3019, 3020, 3021, 3022, 3023, 3024, 3025, 3026, 3027, 3028, 3029, 3030, 3031, 3032, 3033, 3034, 3035, 3036, 3037, 3038, 3039, 3040, 3041, 3042, 3043, 3044, 3045, 3046, 3047, 3048, 3049, 3050, 3051, 3052, 3053, 3054, 3055, 3056, 3057, 3058, 3059, 3060, 3061, 3062, 3063, 3064, 3065, 3066, 3067, 3068, 3069, 3070, 3071, 3072, 3073, 3074, 3075, 3076, 3077, 3078, 3079, 3080, 3081, 3082, 3083, 3084, 3085, 3086, 3087, 3088, 3089, 3090, 3091, 3092, 3093, 3094, 3095, 3096, 3097, 3098, 3099, 3100, 3101, 3102, 3103, 3104, 3105, 3106, 3107, 3108, 3109, 3110, 3111, 3112, 3113, 3114, 3115, 3116, 3117, 3118, 3119, 3120, 3121, 3122, 3123, 3124, 3125, 3126, 3127, 3128, 3129, 3130, 3131, 3132, 3133, 3134, 3135, 3136, 3137, 3138, 3139, 3140, 3141, 3142, 3143, 3144, 3145, 3146, 3147, 3148, 3149, 3150, 3151, 3152, 3153, 3154, 3155, 3156, 3157, 3158, 3159, 3160, 3161, 3162, 3163, 3164, 3165, 3166, 3167, 3168, 3169, 3170, 3171, 3172, 3173, 3174, 3175, 3176, 3177, 3178, 3179, 3180, 3181, 3182, 3183, 3184, 3185, 3186, 3187, 3188, 3189, 3190, 3191, 3192, 3193, 3194, 3195, 3196, 3197, 3198, 3199, 3200, 3201, 3202, 3203, 3204, 3205, 3206, 3207, 3208, 3209, 3210, 3211, 3212, 3213, 3214, 3215, 3216, 3217, 3218, 3219, 3220, 3221, 3222, 3223, 3224, 3225, 3226, 3227, 3228, 3229, 3230, 3231, 3232, 3233, 3234, 3235, 3236, 3237, 3238, 3239, 3240, 3241, 3242, 3243, 3244, 3245, 3246, 3247, 3248, 3249, 3250, 3251, 3252, 3253, 3254, 3255, 3256, 3257, 3258, 3259, 3260, 3261, 3262, 3263, 3264, 3265, 3266, 3267, 3268, 3269, 3270, 3271, 3272, 3273, 3274, 3275, 3276, 3277, 3278, 3279, 3280, 3281, 3282, 3283, 3284, 3285, 3286, 3287, 3288, 3289, 3290, 3291, 3292, 3293, 3294, 3295, 3296, 3297, 3298, 3299, 3300, 3301, 3302, 3303, 3304, 3305, 3306, 3307, 3308, 3309, 3310, 3311, 3312, 3313, 3314, 3315, 3316, 3317, 3318, 3319, 3320, 3321, 3322, 3323, 3324, 3325, 3326, 3327, 3328, 3329, 3330, 3331, 3332, 3333, 3334, 3335, 3336, 3337, 3338, 3339, 3340, 3341, 3342, 3343, 3344, 3345, 3346, 3347, 3348, 3349, 3350, 3351, 3352, 3353, 3354, 3355, 3356, 3357, 3358, 3359, 3360, 3361, 3362, 3363, 3364, 3365, 3366, 3367, 3368, 3369, 3370, 3371, 3372, 3373, 3374, 3375, 3376, 3377, 3378, 3379, 3380, 3381, 3382, 3383, 3384, 3385, 3386, 3387, 3388, 3389, 3390, 3391, 3392, 3393, 3394, 3395, 3396, 3397, 3398, 3399, 3400, 3401, 3402, 3403, 3404, 3405, 3406, 3407, 3408, 3409, 3410, 3411, 3412, 3413, 3414, 3415, 3416, 3417, 3418, 3419, 3420, 3421, 3422, 3423, 3424, 3425, 3426, 3427, 3428, 3429, 3430, 3431, 3432, 3433, 3434, 3435, 3436, 3437, 3438, 3439, 3440, 3441, 3442, 3443, 3444, 3445, 3446, 3447, 3448, 3449, 3450, 3451, 3452, 3453, 3454, 3455, 3456, 3457, 3458, 3459, 3460, 3461, 3462, 3463, 3464, 3465, 3466, 3467, 3468, 3469, 3470, 3471, 3472, 3473, 3474, 3475, 3476, 3477, 3478, 3479, 3480, 3481, 3482, 3483, 3484, 3485, 3486, 3487, 3488, 3489, 3490, 3491, 3492, 3493, 3494, 3495, 3496, 3497, 3498, 3499, 3500, 3501, 3502, 3503, 3504, 3505, 3506, 3507, 3508, 3509, 3510, 3511, 3512, 3513, 3514, 3515, 3516, 3517, 3518, 3519, 3520, 3521, 3522, 3523, 3524, 3525, 3526, 3527, 3528, 3529, 3530, 3531, 3532, 3533, 3534, 3535, 3536, 3537, 3538, 3539, 3540, 3541, 3542, 3543, 3544, 3545, 3546, 3547, 3548, 3549, 3550, 3551, 3552, 3553, 3554, 3555, 3556, 3557, 3558, 3559, 3560, 3561, 3562, 3563, 3564, 3565, 3566, 3567, 3568, 3569, 3570, 3571, 3572, 3573, 3574, 3575, 3576, 3577, 3578, 3579, 3580, 3581, 3582, 3583, 3584, 3585, 3586, 3587, 3588, 3589, 3590, 3591, 3592, 3593, 3594, 3595, 3596, 3597, 3598, 3599, 3600, 3601, 3602, 3603, 3604, 3605, 3606, 3607, 3608, 3609, 3610, 3611, 3612, 3613, 3614, 3615, 3616, 3617, 3618, 3619, 3620, 3621, 3622, 3623, 3624, 3625, 3626, 3627, 3628, 3629, 3630, 3631, 3632, 3633, 3634, 3635, 3636, 3637, 3638, 3639, 3640, 3641, 3642, 3643, 3644, 3645, 3646, 3647, 3648, 3649, 3650, 3651, 3652, 3653, 3654, 3655, 3656, 3657, 3658, 3659, 3660, 3661, 3662, 3663, 3664, 3665, 3666, 3667, 3668, 3669, 3670, 3671, 3672, 3673, 3674, 3675, 3676, 3677, 3678, 3679, 3680, 3681, 3682, 3683, 3684, 3685, 3686, 3687, 3688, 3689, 3690, 3691, 3692, 3693, 3694, 3695, 3696, 3697, 3698, 3699, 3700, 3701, 3702, 3703, 3704, 3705, 3706, 3707, 3708, 3709, 3710, 3711, 3712, 3713, 3714, 3715, 3716, 3717, 3718, 3719, 3720, 3721, 3722, 3723, 3724, 3725, 3726, 3727, 3728, 3729, 3730, 3731, 3732, 3733, 3734, 3735, 3736, 3737, 3738, 3739, 3740, 3741, 3742, 3743, 3744, 3745, 3746, 3747, 3748, 3749, 3750, 3751, 3752, 3753, 3754, 3755, 3756, 3757, 3758, 3759, 3760, 3761, 3762, 3763, 3764, 3765, 3766, 3767, 3768, 3769, 3770, 3771, 3772, 3773, 3774, 3775, 3776, 3777, 3778, 3779, 3780, 3781, 3782, 3783, 3784, 3785, 3786, 3787, 3788, 3789, 3790, 3791, 3792, 3793, 3794, 3795, 3796, 3797, 3798, 3799, 3800, 3801, 3802, 3803, 3804, 3805, 3806, 3807, 3808, 3809, 3810, 3811, 3812, 3813, 3814, 3815, 3816, 3817, 3818, 3819, 3820, 3821, 3822, 3823, 3824, 3825, 3826, 3827, 3828, 3829, 3830, 3831, 3832, 3833, 3834, 3835, 3836, 3837, 3838, 3839, 3840, 3841, 3842, 3843, 3844, 3845, 3846, 3847, 3848, 3849, 3850, 3851, 3852, 3853, 3854, 3855, 3856, 3857, 3858, 3859, 3860, 3861, 3862, 3863, 3864, 3865, 3866, 3867, 3868, 3869, 3870, 3871, 3872, 3873, 3874, 3875, 3876, 3877, 3878, 3879, 3880, 3881, 3882, 3883, 3884, 3885, 3886, 3887, 3888, 3889, 3890, 3891, 3892, 3893, 3894, 3895, 3896, 3897, 3898, 3899, 3900, 3901, 3902, 3903, 3904, 3905, 3906, 3907, 3908, 3909, 3910, 3911, 3912, 3913, 3914, 3915, 3916, 3917, 3918, 3919, 3920, 3921, 3922, 3923, 3924, 3925, 3926, 3927, 3928, 3929, 3930, 3931, 3932, 3933, 3934, 3935, 3936, 3937, 3938, 3939, 3940, 3941, 3942, 3943, 3944, 3945, 3946, 3947, 3948, 3949, 3950, 3951, 3952, 3953, 3954, 3955, 3956, 3957, 3958, 3



Bureau Veritas Consumer  
Products Services  
Germany GmbH  
Businesspark A&B  
Ludwigshafen  
Deutschland  
+49 (0) 40 749 41 - 0  
cpa-veritas@bureauveritas.com

## Verklaring van geen bezwaar

**Aanvrager:** Delta Energy Systems Germany GmbH  
Tschudinstraße 21  
79331 Tettingen  
Deutschland

**Product:** Automatisch schakelstation tussen een netparallelle  
zelfopwekinstallatie en het openbare laagspanningsnet

**Model:** SOLVIA15EUG4TL; SOLVIA20EUG4TL

**Reglementair voorgeschreven gebruik:**  
Automatisch schakelstation met driedraags netverbinding conform DIN VDE V 0126-1-1:2006-02  
voor fotovoltaïsche installaties met een drieleids parallelverbinding door middel van gelijkstroom-  
wiskelstroombewakking in het net van de drieleids parallelverbinding. Het automatische schakelstation vormt  
een integraal bestanddeel van de hoger vermelde transformatorloze gelijkstroom-wiskelstroombewakking.  
Deze dient als vervangingsmiddel voor een te allen tijde voor de distributienetexploitant ("VNE")  
toegestelde afsluiting met schakelfunctie.  
\* netspanning 230V  
\* frequentie 49/50/52 Hz  
\* schakeling 10/1.0s

**Controlebasis:**  
DIN VDE V 0126-1-1:2006-02, EN 50438:2007 en Zelfopwekinstallaties aan het  
laagspanningsnet, 4<sup>de</sup> uitgave 2001, richtlijn voor aansluiting en parallelle verwerking van  
zelfopwekinstallaties aan laagspanningsnetten met VDN supplementen, september 2005 van de "Verband  
der Elektrofachverbände" (VDE) en van de "Verband der Netzbetreiber" (VDN).  
Een representatief testpatroon van het hoger vermelde product voldoet aan de op het moment van de  
uitkering van dit attest geldende veiligheids-eisen van de vermelde controlegrondgegevens  
voor een reglementair voorgeschreven gebruik.

**Rapportnummer:** 11TH0291-VDEB126\_NED\_DeTte  
**Certificaatnummer:** U11-900  
**Datum:** 2011-09-29 **Geldig tot:** 2014-09-28

Achim Hanchen



Bureau Veritas Consumer  
Products Services  
Germany GmbH  
Businesspark A&B  
Ludwigshafen  
Deutschland  
+49 (0) 40 749 41 - 0  
cpa-veritas@bureauveritas.com

## Certificado de conformidad

**Requerente:** Delta Energy Systems Germany GmbH  
Tschudinstraße 21  
79331 Tettingen  
Alemania

**Producto:** Microgenerador en paralelo con redes de distribución  
pública de baja tensión

**Modelo:** SOLVIA15EUG4TL; SOLVIA20EUG4TL

**Utilización de acuerdo con los reglamentos:**  
Dispositivo de desconexión automática con neutralización de la red trifásica para sistemas fotovoltaicos  
con un circuito paralelo trifásico a través de un inversor en la alimentación por la red pública. O  
dispositivo de desconexión automática es parte integrante del inversor anteriormente mencionado.

**Reglas y normas aplicadas:**  
Este producto cumple con los requisitos de protección de interfaz para Portugal. O  
SOLVIA15EUG4TL; SOLVIA20EUG4TL  
requisitos básicos de la norma estado cumplidos.  
Límites básicos:  
potencia máxima 30 V  
subtensión 180 V V  
frecuencia 50/52 Hz  
subtensión 1,7/1,7 s

Alguno de la emisión de este certificado, el concepto de protección de interfaz de un producto  
representativo anteriormente mencionado corresponde a especificaciones de seguridad válidas para la  
instalación y el uso. Los tests y certificación fueron realizados de  
acuerdo con la norma ISO / IEC sistema 5 - Guía 67:2004

**Número de relatorio:** 11TH0291-EN50438\_DeTte  
**Número de certificado:** U11-903 **Válido até:** 2014-09-29  
**Data de emissão:** 2011-09-30

Achim Hanchen

Certificate No.: SGS/110763

# CERTIFICATE OF COMPLIANCE

This certificate is issued to confirm that **SGS Systems & Services Certification Pty Ltd** (Electrical Product Certification Services (EPCS) Australia) has certified the equipment / appliance / accessory described hereunder to comply with the minimum safety standards for which the Application has been made by :-

DELTA ENERGY SYSTEM GERMANY GMBH  
Tscheulinstraße 21 79331 Teningen  
GERMANY

## DESCRIPTION OF ELECTRICAL EQUIPMENT

**Class:** Grid Connected Inverter Energy System  
**Product:** Solar Inverter

Trade Name / Manufacturer:  
Catalogue / Model No(s):

**atings:**  
 Input: 100 VAC, 50/60 Hz, 1000 VA  
 Output: 350-600 V a.c., 1000 VA  
 Transformer: 230/240 V a.c., 30-100 VA, 50/60 Hz, Class 1, IP55/IP55  
 Input: 230/240 V a.c., F0E48010862  
 SOLVA12/VEIGUITA / F0E48010862  
 Input: 46 A (23 A per string), Output: 25 A, 15000 W, max 15750 W  
 SOLVA20/VEIGUITA / F0E48010864  
 Input: 60 A (30 A per string), Output: 30 A, 20000 W  
 AS/NZS 1100:2009 + A1  
 AS/NZS 2:2005 and AS 4777.3:2005

Standard No.:

MARKING:	SGSE/110763
EXPIRY DATE:	16 November 2016
DATE OF CERTIFICATION:	17 November 2011

*C. Tushnet*



SGS EPCS Australia, 450 Princess Highway, Noble Park, VIC 3174, AUSTRALIA

# Konformitätsnachweis

## Erzeugungseinheit

### NA-Schutz

**Antragsteller:** Delta Energy Systems Germany GmbH  
Tscheulinstraße 21  
79331 Teningen  
Deutschland

**Produkt:** Photovoltaik Wechselrichter mit integriertem NA-Schutz

Modell:	SOLVIA20EUG4TL	SOLVIA15EUG4TL
max. Scheinleistung $S_{\text{max}}$ :	20,0kVA	15,75kVA
Nennmessungsspannung:	3Ph/ N/ PE, 230/400V, 50Hz	
Software Version:	Rep: 1.07 DSP: 1.24	

Die oben bezeichneten Erzeugungseinheiten mit integriertem NA-Schutz erfüllen die Anforderungen der VDE-AR-N 4105.

**Netzanschlussregel:**

**VDE-AR-N 4105:2011-08**  
Erzeugungsanlagen am Niederspannungsnetz – Technische Mindestanforderungen für Anschluss und Parallelbetrieb von Erzeugungsanlagen am Niederspannungsnetz.

Ein repräsentatives Testmuster des oben genannten Ergebnisses entspricht zum Zeitpunkt der Ausstellung dieser Bescheinigung der aufgeführten Netzanschlussregel.

Berichtsnummer: 11KFS109-01\_0

Zertifikatsnummer: 11-076-00

<b>Ausstellungsdatum:</b>	2011-11-17	<b>Gültig bis:</b>	2014-11-17
---------------------------	------------	--------------------	------------

Dr. K.

**Horst Haug**  
Zertifizierstelle





## EC Declaration of Conformity

Producer: Delta Energy Systems (Germany) GmbH  
Address: Tschelstr. 21, D - 78331 Tettingen, Germany

Product description: Solar Inverter for Grid operation

Model: SOLIMA18EUG4TL EOE48010362  
SOLIVA18EUG4TL EOE48010364

The product described above is in the form as delivered is in conformity with the provisions of the following European Directives:

2004/108/EC Council Directive on the approximation of the laws of the Member States relating to electromagnetic compatibility

EN 55014-1 : 2006 + A1 : 2009  
EN 55014-2 : 2006 + A1 : 2009  
EN 61000-4-2 : 2008  
EN 61000-4-3 : 2010  
EN 61000-4-3 : 2010  
EN 61000-4-4 : 2006  
EN 61000-4-5 : 2005  
EN 61000-4-6 : 2008  
EN 61000-4-7 : 2009  
EN 61000-4-8 : 2009  
EN 61000-4-9 : 2009  
EN 61000-5-1 : 2009  
EN 61000-6-1 : 2007  
EN 61000-6-2 : 2005 / EN 61000-6-1 : 2007  
EN 61000-6-3 : 2007 / EN 61000-6-1 : 2007  
EN 61000-6-4 : 2007

2006/95/EC Council Directive on the approximation of the laws of the Member States relating to electrical equipment designed for use within certain voltage limits

EN 62109-1 : 2010  
EN 62109-2 : 2011

The product described above does also comply with the VDE 0124-100.

Tettingen, July 7<sup>th</sup> 2012

Vincent Lin

Name, Function

Signature

Name, Function

Signature

Andreas Heitschen

Head of BU LOB ISPV

Signature

Name, Function

Signature

This declaration certifies the conformity to the specified directives but contains no assurance of properties. The safety documentation accompanying the product shall be consulted in detail.

Deszha

SOLIMA18EUG4TL EC\_Decl en 20127.doc



approval  
specialists

## Supplier's Declaration of Conformity

As required by Notices under:

section 182 of the *Radiocommunications Act 1992*;

This completed form remains with the supplier as part of the documentation required for the compliance records.

### SUPPLIERS DETAILS

Name of Agent Approval Specialists Pty. Limited	ACA Supplier Code Number, or N 4 2 9 2
Address of Manufacturer, Importer or Agent 259 Packard Ave	
Castle Hill, NSW 2154, AUSTRALIA	Australian Company Number (ACN) 0 9 4 6 5 6 3 5 4

### PRODUCT DETAILS

Product Name, Type and Model Delta Energy System: PV Inverter; Model: SOLIVA18EUG4TL-EOE48010364 & SOLIMA18EUG4TL-EOE48010362
---

### APPLICABLE STANDARDS

Standard Title, Number and if applicable the Test Report Number EN 61000-6-3: 2007 Generic Standards - Emission standard for residential, commercial and light-industrial environments via report TS11060124-EME from Intertek Testing Services Taiwan Ltd., Hsinchu City, Taiwan dated July 29, 2011.
---

### DECLARATION

I hereby declare that the product mentioned above complies with the above mentioned standards and all products supplied under this Declaration will be identical to the sample identified above.

Signature of Authorised Person 	Date 09 Dec 2011
Print Name Martin Garwood	Position in Organisation Managing Director

Bureau Veritas  
Products Services  
Germany GmbH  
Bismarckstr. 66  
D-40700 Essen  
Deutschland  
Tel.: +49 (0) 201 407 00 10  
Fax: +49 (0) 201 407 00 10  
E-Mail: [info@bureauveritas.com](mailto:info@bureauveritas.com)  
Zertifizierungsstelle der BV CPS GmbH  
Akreditiert nach EN 45011  
ISO 15011



Einheitszertifikat

Hersteller:  
Delta Energy Systems Germany GmbH  
Tischelstr. 21  
79331 Tettnigen  
Germany

Type Erzeugungseinheit:	Solar Inverter	SOLVIA1 SEUG4TL	SOLVIA20EUG4TL
Technische Daten:	Nennschleifleistung:	15kVA	20kVA
	Nennwirkleistung:	15 kW	20kW
	Nennspannung:	400/230V, 3p/n/PE	
	Nennfrequenz:	50 Hz	

**Firmarevision**  
1.70

**Netzanschlussregel:**  
BDEW-Richtlinie „Erzeugungsanlagen am Mittelspannungsnetz“  
Richtlinie für Anschluss und Parallelbetrieb von Erzeugungsanlagen am  
Mittelspannungsnetz, 2008 und Ergänzung 1/2009, 7/2010 und 2/2011

**Mitteltende Normen /**  
DN EN 61400-21:2008

**Richtlinien:**  
Technische Richtlinien: TR3 Rev. 22, TR4 Rev. 5, TR8 Rev. 5  
TransmissionCode 2007

Die oben bezeichnete Erzeugungseinheit wurde nach den in der Netzanschlussregel referenzierten, technischen Richtlinien genehmigt und ist für den Betrieb in der angegebenen Leistungsfähigkeit geeignet. Die Erzeugungseinheit wird an elektrischen Eigenschaften geprüft und erfüllt:  
Erzeugung und Regelung von Wirk- und Blindleistung  
Verhalten der Erzeugungseinheit bei Netzstörungen (Blindleistungscharakteristika gemäß TransmissionCode 2007)  
Schutzanordnung auf Einzelebene\*  
Ausweis der Netzrückwirkungen  
Validiertes Einheitsmodell: Delta\_12\_074\_TR4\_SOLVIA1SEUG4TL\_V1  
Delta\_12\_074\_TR4\_SOLVIA20EUG4TL\_V1  
Der Hersteller hat die Zertifizierung seiner Erzeugungseinheiten nach ISO 9001 nachgewiesen.  
\* Eine erforderliche Prüfkommunikation ist separat an einer übergebenen Schutzanordnung zu gewährleisten.

**Das Zertifikat beinhaltet folgende Angaben:**  
Technische Daten der Erzeugungseinheit, der eingesetzten Hilfsanlagen und der verwendeten Softwareversion  
Den schematischen Aufbau der Erzeugungseinheit  
Zusammengefasste Angaben zu den Eigenschaften der Erzeugungseinheit

BV Projektnummer: 11TH0291  
Zertifikatsnummer: 12-074  
Ausstellungsdatum: 2012-04-26  
Gültig bis: 2017-04-01

Zertifizierungsstelle

Dieter Zitzmann  
(Eine auszugswerte Darstellung des Zertifikats bedarf der schriftlichen Genehmigung der BV CPS GmbH)





**Delta Energy Systems (Germany) GmbH**

Tscheulinstrasse 21

79331 Teningen

Germany

Sales Email: [sales@solar-inverter.com](mailto:sales@solar-inverter.com)

Support Email: [support@solar-inverter.com](mailto:support@solar-inverter.com)

Sales Hotline: 0180 10 SOLAR (76527)

Support Hotline: 0180 16 SOLAR (76527)

Mondays to Fridays from 8 am to 5 pm (apart from official Bank Holidays)  
(3.9 ct/min.)

**Delta Energy Systems (Australia) Pty Ltd**

Unit 6, 25 Howleys Road,

Notting Hill - VIC 3168,

Australia

Business Email: [info.australia@solar-inverter.com](mailto:info.australia@solar-inverter.com)

Support Email: [support.australia@solar-inverter.com](mailto:support.australia@solar-inverter.com)

Tel: +61 3 9543 3720 (business inquiry)

+61 3 9543 3053 (service support)

Fax: +61 3 9544 0606



5012299000 00

August 23, 2012

